




V-RAPTOR 250CC ENGINE PARTS PRICE LIST



NO.	PARTS NO.	DESCRIPTION (CHIN)	DESCRIPTION (ENGLISH)	序号 S. N	内部件号 Part Number	DESCRIPTION (ENGLISH)	QTY	LONCIN NEW PARTS NUMBER
E-1发动机全套密封垫及油封(All the engine seals, gaskets and o-rings)								
1	LX250L-A	发动机 全套 油封立 机250 CC	ENGINE OIL SEAL SET 250CC	15	380840119-0001	RING	1	
				7	380840083-0001	O-RING	2	
				11	380650015-0001	OIL SEAL	1	
				12	380840006-0001	O-RING	1	
				9	380840026-0001	O-RING	1	
				12	380840080-0001	O-RING	1	
				16	380840078-0001	O-RING	1	
				7	380840067-0001	O-RING	3	
				10	380650006-0001	OIL SEAL	1	
				11	380650009-0001	OIL SEAL	1	
				12	380840014-0001	O-RING	2	
2	LX250L-B	发动机 全套 密封垫 立机25 0CC	ENGINE GASKETS SET 250CC	9	120150042-0001	GASKET,CYLINDER	1	
				16	120310002-0001	GASKET,LCYLINDER HEAD SIDE COVER	1	
				20	120050007-0001	CYLINDER GASKET	1	
				2	110620001-0001	GASKET, R.CRANKCASE COVER	1	
				3	110100008-0001	GASKET,CRANKCASE	1	


E-2 气缸头/气缸体/凸轮轴/气门(CYLINDER HEAD/CYLINDER BODY/CAMSHAFT/VALVE)



1	LX250L-C	汽缸头 与 气门组 合件	CYLINDER HEAD ASSY WITH VALVE SET	1	500260120-0006	CYLINDER HEAD	1	500260119-0015
				2	380140030-0005	BOLT	4	
				3	380600001-0001	POSITION PIN	2	380600012-0001
				10	380180023-0002	STUD	2	380180023-0004
				21	140400001-0001	SEAL, VALVE STEM	2	
				22		BUSH	1	
				23	140020015-0001	CAMSHAFT ASSY	1	
				24	140450004-0001	ROCKER ARM	2	
				25	140510005-0001	ROCKER ARM	2	
				26	140530001-0001	VALVE STOPPER	1	
				27	140300012-0001	VALVE INLET	1	
				28	140310012-0001	VALVE EXHAUST	1	
				29	140350003-0001	SPRING, VALVE OUTER	2	
				30	140340004-0001	SPRING, VALVE INNER	2	
				31	140380004-0001	SEAT	2	
				32	140370001-0001	SEAT, OUTER	2	
				33	140360001-0001	SEAT, INNER	2	
				34	140390004-0001	VALVE CLAMP	4	
				35	140480003-0001	COFTER, VALVE	2	


				36	140490002-0001	VALVE CLEARANCE ADJUSTING NUT	2	
				37	380220010-0001	SCREW	1	
				38	140460006-0001	ROCKER ARM	2	
				39	140330003-0001	SPRING, VALVE	2	
2	270960001-0001	火花塞	SPARK PLUG	4	270960001-0001	SPARK PLUG	1	
3	120280001-0012	气门盖	CAP,TAPPET ADJUSTING HOLE	5	120280001-0012	CAP,TAPPET ADJUSTING HOLE	2	120280001-0002
4	380840067-0001	密封圈	RING	6	380840067-0001	RING	2	
5	380330015-0004	盖形螺母	NUT,CAP,M6	7	380330015-0004	NUT,CAP,M6	4	380330038-0004
6	380450012-0001	平垫圈	WASHER,ASEALING	8	380450012-0001	WASHER,ASEALING	4	
7	120150042-0001	气缸头密封垫	GASKET,CYLINDER	9	120150042-0001	GASKET,CYLINDER	1	
8	180420436-0001	进气管	INLET PIPE	11	180420436-0001	INLET PIPE	1	180420372-0001
9	380450138-0001	平垫圈	WASHER	12	380450138-0001	WASHER	1	
10	380140230-0001	六角头法兰面螺栓	BOLT	13	380140230-0001	BOLT	1	
11	120300018-0001	气缸头左侧盖	COVER,LCYLINDER HEAD SIDE	14	120300018-0001	COVER,LCYLINDER HEAD SIDE	1	120300018-0011
12	380840119-0001	密封圈	RING	15	380840119-0001	RING	1	
13	120310002-0001	气缸头左侧盖密封垫	GASKET,LCYLINDER HEAD SIDE COVER	16	120310002-0001	GASKET,LCYLINDER HEAD SIDE COVER	1	120310008-0001
14	380140002-0006	六角头法兰面螺栓	BOLT	17	380140002-0006	BOLT	2	380140015-0006
15	380600002-0001	定位销	POSITION PIN	18	380600002-0001	POSITION PIN	2	380600004-0001
16	120020093-0008	气缸体	CYLINDER BODY COMP	19	120020093-0008	CYLINDER BODY COMP	1	120020093-0020
17	120050007-0001	气缸体密封垫	CYLINDER GASKET	20	120050007-0001	CYLINDER GASKET	1	120050056-0001

E-3 链条张紧器 (CAM CHAIN/TENSIONER)




1	LX250L-D	链轮链条传动组件	SPROCKET AND CHAIN SET	1	140580013-0001	SPROCKET CAM	1	
				2	140610012-0001	CHAIN CAM	1	
				4	141000010-0001	PLATE, GUIDE CHAIN	1	
				5	380070140-0001	BOLT	1	
2	LX250L-E	链条涨紧器组合件	CHAIN TENSIONER SET	3	140960008-0001	ARM COMP CAM CHAIN TENSIONER	1	
				6	380450056-0001	WASHER	1	
				7	141040001-0003	PIN, ARM COMP CAM CHAIN TENSIONER	1	
				8	140750015-0001	TENSIONER	1	140750033-0006
				9	140830004-0001	GASKET	1	
				10	380840014-0001	O-RING	1	
				11	140800001-0001	BOLT	1	
				12	380070015-0005	BOLT	2	380140002-0006

E-4 右曲轴箱盖 (RIGHT CRANKCASE COVER)




1	110600114-0035	右曲轴箱盖	R.CRANKCASE COVER	1	110600114-0035	R.CRANKCASE COVER	1	110600263-0006
2	110620001-0001	右曲轴箱盖密封垫	GASKET, R.CRANKCASE COVER	2	110620001-0001	GASKET, R.CRANKCASE COVER	1	110620036-0001
3	380140019-0006	六角法兰面螺栓	BOLT	3	380140019-0006	BOLT	9	
4	110700002-0003	机油尺	GAUGE OIL LAVER	4	110700002-0003	GAUGE OIL LAVER	1	
5	LX250L-F	离合器操纵杆组合件	LEVER ASSY,CLUTCH	5	190810006-0002	LAVER COMP CLUTH	1	190810050-0002
				6	191210001-0001	PIN	1	
				7	380840083-0001	O-RING	2	
				8	381160009-0001	SPRING	1	381160142-0001
6	380600002-0001	定位销	POSITION PIN	9	380600002-0001	POSITION PIN	2	
7	380140020-0003	六角法兰面螺栓	BOLT	10	380140020-0003	BOLT	3	
8	380650015-0001	油封	OIL SEAL	11	380650015-0001	OIL SEAL	1	
9	380840006-0001	密封圈	O-RING	12	380840006-0001	O-RING	1	
10	110630001-0001	机油观察窗	SIGHT GLASS, OIL	13	110630001-0001	SIGHT GLASS, OIL	1	110630002-0001

E-5 机油泵/机油滤清器(OIL PUMP/OIL FILTER COMP)




1	150010008-0001	机油泵 部件	OIL PUMP ASSY	1	150010008-0001	OIL PUMP ASSY	1	150070005-0001
				2	380220001-0001	SCREW	2	
				3	380570018-0001	CLIP	1	
				4	150070020-0001	DRIVE GEAR,OIL PUMP	1	
				5	150020004-0001	BODY, OIL PUMP	1	
				6	150060003-0001	OUTER ROTOR	1	
				7	150050004-0001	INNER ROTOR	1	
				8	150080004-0001	DRIVESHAFT, OIL PUMP COVER	1	
				9	380610036-0001	PIN	1	
				10	150040002-0001	COVER,OIL PUMP GEAR	1	
				11	380220005-0001	SCREW	2	
				12	380840014-0001	O-RING	2	
2	150350011-0001	机油精 滤器组 合	OIL FILTER COMP	13	150350011-0001	OIL FILTER COMP	1	150040002-0001
				14	150520001-0001	OIL TUBE	1	
				15	380220005-0001	BOLT	3	380220002-0001
				16	381150004-0001	SPRING,EX.OIL TUBE	1	
				17	150360001-0001	COVER, FINE OIL FILTER	1	150360013-0001
				18	381350001-0001	CLIP, THRUST	1	
				19	380810003-0001	NUT	1	
				20	380480001-0001	WASHER	1	
				21	150540001-0001	GASKET, FINE OIL FILTER	1	
				22	150490001-0001	SEAT, OIL FILTER	1	150490006-0001

E-6 离合器 (CLUTCH)



1	500280113-0001	离合器 套件	CLUTCH COMP	1	500280113-0001	CLUTCH COMP	1	
				2	190730007-0001	ASLE SLEEVE SEPARATING	1	
				3	380070015-0001	BOLT	6	380140048-0001
				4	380630021-0001	BEARING, CLUTCH COVER	1	
				5	190480005-0001	LIFT PLATE	1	
				6	380810003-0001	NUT	1	
				7	190550017-0001	SPRING	6	190550002-0001
				8	380480001-0001	COLLAR	1	
				9	190400006-0001	CENTER PIECE	1	190400002-0001
				10	190430005-0001	FRICITION PLATE, DRIVE	6	
				11	190460005-0001	FRICITION PLATE, DRIVEN	5	
				12	190470004-0001	CLAMP PLATE	1	
				13	380500001-0001	WASHER (B)	1	
				14	190330008-0001	COVER ASSY, CLUTCH	1	
				15	190030003-0001	PRIMARY DRIVE GEAR	1	


E-7 磁电机\左曲轴箱盖 (CENERATOR\COVER L.CRANKCASE)



1	270010048-0012	磁电机 组件	MAGNETO	1	270010048-0012	MAGNETO	1	
				2	270020052-0001	FLY WHEEL COMP	1	
				3	270100006-0006	STSTOR ASSY	1	270100058
				4	380140016-0005	BOLT	2	
2	110480007-0001	压线板	CABLE SLEEVE	5	110480007-0001	CABLE SLEEVE	1	110480028-0001
3	380070141-0001	六角头 螺栓	BOLT	6	380070141-0001	BOLT	1	380140026-0006
4	380200008-0001	六角头螺 钉	BOLT	7	380200008-0001	BOLT	2	380200008-0005
5	380140016-0005	六角头 法兰面 螺栓	BOLT	8	380140016-0005	BOLT	3	380140016-0005
6	LX250L-G	视孔盖 及左装 饰盖	CAP, GENERATO R AND COVER, LDECORATIVE	9	380840026-0001	O-RING	1	
				10	110440001-0007	CAP EYEHOLE	1	110440001-0003
				16	380840078-0001	O-RING	1	
				17	110430002-1727	COVER, L.DECORATIVE	1	110430002-0025
7	110400036-0001	左前盖	L.CRANKCASE COVER	11	110400036-0001	L.CRANKCASE COVER	1	110400177-0003
8	380840080-0001	密封圈	O-RING	12	380840080-0001	O-RING	1	380840080-0001
9	110460007-0008	齿轮室 盖	COVER, GEAR BOX	13	110460007-0008	COVER, GEAR BOX	1	110400177-0003
10	380140016-0005	六角头 法兰面 螺栓	BOLT	14	380140016-0005	BOLT	3	380140015-0006
11	380140020-0003	六角头 法兰面 螺栓	BOLT	15	380140020-0003	BOLT	2	

12	380140068-0004	八角头 法兰面 螺栓	BOLT	18	380140068-0004	2 BOLT	1	
13	380140019-0006	八角头 法兰面 螺栓	BOLT	19	380140019-0006	2 BOLT	1	
14	380140020-0003	八角头 法兰面 螺栓	BOLT	20	380140020-0003	2 BOLT	1	
15	380630035-0001	轴承	BEARING	21	380630035-0001	2 BEARING	1	380140031-0004


E-8 曲轴箱体 (CRANKCASE ASSEMBLY)



1	LX250L-H	左右曲轴箱体		1	110080087-0008	R.CRANKCASE ASSY	1	110080087-0014
				2	110030134-0008	L.CRANKCASE ASSY	1	110030134-0016
2	110100008-0001	曲轴箱密封垫	GASKET,CRANKCASE	3	110100008-0001	GASKET,CRANKCASE	1	110100040-0001
3	LX250L-I	双头螺栓	STUD	4	110250021-0001	STUD (B)	2	
				5	110240027-0001	STUD (A)	2	
4	120280001-0012	气门盖	SCREW COVER	6	120280001-0012	SCREW COVER	1	120280001-0002
5	380840067-0001	密封圈	O-RING	7	380840067-0001	O-RING	1	
	381150014-0001	压簧	SPRING,OIL FILTER ELEMENT	8	381150014-0001	SPRING,OIL FILTER ELEMENT	1	
6	150290001-0001	机油滤网	FILTER ELEMENT COMP	9	150290001-0001	FILTER ELEMENT COMP	1	
7	380650006-0001	油封	OIL SEAL	10	380650006-0001	OIL SEAL	1	380650008-0001
	380650009-0001	油封	OIL SEAL	11	380650009-0001	OIL SEAL	1	
8	191230003-0002	离合器拉筋定位板	CLUTSH CABLE STAND	12	191230003-0002	CLUTSH CABLE STAND	1	
9	380600001-0001	定位销	PIN	13	380600001-0001	PIN	4	
	380140020-0003	六角头法兰面螺栓	BOLT	14	380140020-0003	BOLT	9	
10	380140020-0003	六角头法兰面螺栓	BOLT	15	380140020-0003	BOLT	1	


11	380950004-0001	管夹	SPRING,CLAMP	16	380950004-0001	SPRING,CLAMP	1	
	380740003-0001	通气管	BREATH PIPE	17	380740003-0001	BREATH PIPE	1	
12	380140031-0004	八角头法兰面螺栓	BOLT	18	380140031-0004	BOLT	1	380040001-0005

E-9 曲轴 活塞 CRANKCASE&PISTON



1	LX250L-J	活塞组件	PISTON ASSY.	1	130070032-0001	PISTON RING	1	
				2	380560001-0001	CIRCLIP,PISTON PIN	2	
				3	130060001-0001	PISTON PIN	1	
				4	130030031-0002	PISTON	1	130030190-0001
2	130140038-0001	曲柄连杆部件	CRANKSHAFT CONNETING ROD COMP	5	130140038-0001	CRANKSHAFT CONNETING ROD COMP	1	
				6	130350001-0001	CRANK PIN	1	
				7	380630011-0001	NEEDLE BEARING	1	
				8	130150021-0001	CONNETING ROD	1	
				9	380630103-0001	CRANKSHAFT BEARING.R	1	380630014-0001
				10	130260030-0001	CRANKSHAFT.R	1	
				11	130210028-0001	CRANKSHAFT.L	1	
				12	380620001-0001	SEMI CIRCLAR KEY	1	
				13	130230010-0001	CRANKSHAFT TIMING GEAR	1	
3	380140041-0001	六角头法兰面螺栓	BOLT	15	380630103-0001	CRANKSHAFT BEARING.L	1	380630009-0001
				14	380140041-0001	BOLT	1	

E-10 主副轴 \变速机构MAIN\COUNTERSHAFT\ VARIABLE UNIT




				1	500290130-0001	CYLINDER HEAD ASSY	1	500290084-0001
				12	191250059-0001	MAINSHAFT, TRANSMISSION ASSY	1	
				2	380540003-0001	CIRCLIP	1	
				3	191280023-0001	DRIVING GEAR, 2ND	1	
				4	191330011-0001	DRIVING GEAR, 5TH	1	
				5	380500002-0001	CIRCLIP, GEARSHIFT PLATE	1	
				6	380550010-0001	CIRCLIP	1	
				7	191300019-0001	DRIVING GEAR, 4TH	1	
				8	191290024-0001	DRIVING GEAR, 3RD	1	
				9	191260031-0001	MAINSHAFT, TRANSMISSION	1	
				10	380540004-0001	CIRCLIP	1	
				11	191350009-0001	STARTING GEAR COMP	1	
				13	191390076-0001	COUNTERSHAFT ASSY	1	191390082-0001
				14	380540005-0002	CIRCLIP	1	
				15	191560010-0001	STARTING IDLE GEAR	1	
				16	380820024-0001	BUSH, STARTING IDLE GEAR	2	

1	LX250L-K	主副轴 及 变速毂 套件	TRANSMISSION ASSY	17	380540006-0001	THRUST WASHER	2	
				18	191420027-0001	DRIVN GEAR, 1ST	1	
				19	191460025-0001	DRIVEN GEAR, 3RD	1	
				20	380550010-0001	WASHER	1	
				21	380500002-0001	WASHER	1	
				22	191480023-0001	DRIVEN GEAR, 4TH	1	
				23	191400038-0001	SPLINED CLAMP	1	
				24	380540003-0001	CIRCLIP	1	
				25	191500012-0001	DRIVEN GEAR, 5TH	1	
				26	191440024-0001	DRIVEN GEAR, 2TH	1	
				27	380540007-0001	WASHER	1	
				28	380630005-0001	BEAR	1	
				32	380630004-0001	ROLLING BEARING	2	
				33	380630006-0001	ROLLING BEARING	1	
				34	192060002-0001	SENSOR ENGINE	1	191400061-0001
				37	192100002-0001	BOLT	1	
				38	380070014-0005	SHIFT CAM	1	
				39	380600003-0001	PIN	1	
				40	192080002-0001	SHIFT DRUM	1	
				41	192130001-0001	FORK SHAFT	1	
				42	192120003-0001	FORK,3	1	
				43	192120002-0001	FORK,2	1	
				44	192120001-0001	FORK,1	1	
2	LX250L-L	主动链 轮组件	DRIVING SPROCKET	29	191600006-0001	DRIVING SPROCKET	1	191600005-0002
				30	191610001-0002	FIXTURE PLATE	1	
				31	380070141-0001	BOLT	2	
3	192320002-0002	换档臂 部件	PEDAL COMP,GEARSHI FT	35	192320002-0002	PEDAL COMP,GEARSHIFT	1	
				45	380550007-0001	CIRCLIP	1	
				46	381150006-0001	RETURN SPRING,GEAR SHIFT	1	
				47	192370002-0001	GEAR CHANGE PLATE	1	
				48	192340001-0001	GEAR SHIFT	1	
				49	381160004-0001	SPRING, GEAR CHANGE PLATE	1	
				50	380540008-0001	PUSH WASHER	2	
				51	380550008-0001	CIRCLIP	1	
				36	380070015-0005	BOLT	1	380070014-0005


4	LX250L-M	止动板 组件	STOPPER LEVER	52	192190002-0001	STOPPER LEVER	1	
				53	381160010-0001	THRUST SPRING	1	

E-11 启动轴(SPINDLE, KICK STARTER)




1	193300051-0001	启动轴 部件	SPINDLE,KICK STARTER	1	380540012-0001	WASHER	1	380550012-0001
				2	380550031-0001	CIRCLIP	1	
				3	193400001-0001	RATCHET GUIDE PLATE	1	
				4	380540012-0001	WASHER	1	0001
				5	193350001-0001	SPRING.SPINDLE,KICK STARTER	1	
				6	193330001-0001	RATCHET,STARTER DRIVE	1	
				7	380550009-0001	CIRCLIP	1	380550010-0001
				8	380540004-0001	THRUST WASHER	1	
				9	193320001-0001	STARTING GEAR	1	193320022-0001
				10	193310013-0001	SPINDLE,KICK STARTER	1	193310001-0001
				11	193470007-0001	SPRING SEAT	1	
				12	193340001-0001	SPRING, KICK STARTER	1	
				13	380820025-0001	SPRING BVSHING	1	
				14	380540015-0001	WASHER	1	0001
				15	193300051-0001	SPINDLE,KICK STARTER	1	

E-12 启动电机\启动离合器 （STARTING MOTOR \ STARTING CLUTCH）



1	270350039-0025	启动电机组件	STARTING MOTOR	1	270350039-0025	STARTING MOTOR	1	270350039-0026
2	LX250L-N	大小双联齿组合件	GEAR,STARTING IDLE,BIG&SMALL	2	380540026-0001	THRUST WASHER	4	380540117-0001
				3	193200002-0001	GEAR,STARTING IDLE,SMALL	1	193200007-0001
				4	193230003-0001	SHAFT	1	193230012-0001
				5	193190010-0001	GEAR,STARTING IDLE,BIG	1	
				6	380190005-0005	SCREW	3	
3	LX250L-O	启动离合器组合件	STARTING CLUTCH	7	193100005-0001	HOUSING, STARTING CLUTCH	1	19309
				8		SIDE COVER, STARTING CLUTCH	1	19310
				9		GEAR, STARTING CLUTCH	1	19311
				10	193240010-0001	STARTING CLUTCH ASSY	1	

E-13 化油器(CARBURETOR COMP)

							
1	16100--21N00	化油器	CARBURETOR COMP	1	16100--21N00	CARBURETOR COMP	1