



125CC ENGINE PARTS PRICE LIST




NO.	PARTS NO.	DESCRIPTION (ENGLISH)	内部件号 Part Number	DESCRIPTION (ENGLISH)	QTY
-----	-----------	--------------------------	---------------------	-----------------------	-----

E-1 发动机全套密封垫及油封 (All the engine seals, gaskets and o-rings)

1(LX125-A) 2(LX125-B)					
1	LX125-A	ENGINE OIL SEAL SET 125CC	380840045-0001	O-RING	1
			380840046-0001	O-RING	1
			380840132-0001	O-RING	2
			380840042-0001	SEAL	1
			380650029-0001	OIL SEAL	1
			380650056-0001	OIL SEAL	1
			380650054-0001	OIL SEAL	1
			380840048-0001	O-RING	1
			380840064-0001	O-RING	1
			380840005-0001	O-RING	1
			380840026-0001	O-RING	1

			380650061-0001	OIL SEAL	1
			380650031-0001	OIL SEIL	1
2	LX125-B	ENGINE GASKETS SET 125CC	120150022-0001	GASKET, CYLINDER HEAD	1
			120050020-0001	GASKET, CYLINDER	1
			120370001-0001	GASKET, R. CYLINDER HEAD SIDE COVER	1
			120250004-0001	GASKET, CYLINDER HEAD COVER	1
			120310003-0001	GASKET, L. CYLINDER HEAD SIDE COVER	1
			110420008-0001	GASKET,L.CRANKCASE COVER	
			110620010-0001	GASKET, R. CRANKCASE COVER	1
			110100012-0001	GASKET, CRANKCASE	1


E-2 气缸头/气门组件/气缸体(CYLINDER



1	LX125-C	CYLINDER HEAD ASSY WITH VALVE SET	120080110-0007	HEAD. CYLINDER	1
			380180031-0001	STUD	1
			380040003-0001	BOLT	1
			140020004-0001	CAMSHAFT COMP	1
			140200001-0001	REDUCING VALVE	1
			140510002-0001	SHAFT, VALVEROCKER ARM	2
			140490003-0001	NUT, TAPPET ADJUSTING	2
			140480002-0001	SCREW, TAPPET ADJUSTING	2
			140450003-0001	ARM, VALVE ROCKER	2
			140390002-0001	COTTER, VALVE	4
			140380002-0001	RETAINER, VALVE INNER SPRING	2
			140340002-0001	SPRING, VALVE INNER	2

			140350002-0001	SPRING, VALVE OUTER	2
			140370002-0001	SEAT, VALVE OUTER SPRING	2
			140400002-0001	SEAL, VALVE STEM	2
			140300005-0001	VALVE, IN	1
			140310005-0001	CAMSHAFT COMP	1
			140330002-0001	SPRING ASSY, VALVE	2
2	120020055-0004	CYLINDER ASSY	120020055-0004	CYLINDER ASSY	1
3	120150022-0001	GASKET, CYLINDER HEAD	120150022-0001	GASKET, CYLINDER HEAD	1
4	120050020-0001	GASKET, CYLINDER	120050020-0001	GASKET, CYLINDER	1
5	LX125-D	ACCESSORIES FOR CYLINDER	380820091-0001	COLLAR	1
			380840047-0001	RECTANGULAR RIN	1
			380600028-0001	PIN	1
			380600029-0001	PIN	2
			380820089-0001	WASHER	1
			380840045-0001	O-RING	1
			380840046-0001	O-RING	1
			380040007-0001	BOLT	1
6	120060004-0001	DAMPING BUSHING	120060004-0001	DAMPING BUSHING	2
7	120060006-0001	DAMPING BUSHING	120060006-0001	DAMPING BUSHING	1


E-3 气缸头盖 (COVER,CYLINDER HEAD)



1	270960020-0001	SPARK PLUG	270960020-0001	SPARK PLUG	1
2	LX125-E	VALVE CAP WITH O-RING	120280003-0001	VALVE CAP	2
			380840132-0001	O-RING	2
3	LX125-F	CYLINDER HEAD COVER, RIGHT&LEFT SIDE	380140066-0004	BOLTM	1
			380140015-0001	BOLTM	2
			380450048-0001	GASKET	1
			120350004-0002	COVER, CYLINDER HEAD	1
			120370001-0001	GASKET, R. CYLINDER HEAD SIDE COVER	1
			120300009-0006	COVER, L. CYLINDER HEAD SIDE	1
			120310003-0001	GASKET, L. CYLINDER HEAD SIDE COVER	1
4	LX125-G	CYLINDER HEAD COVER WITH FASTEN PARTS	380330017-0001	NUT, CYLINDER HEAD COVER	4
			380450087-0001	GASKET	3
			380450088-0001	GASKET	1
			120230018-0001	GOVER, CYLINDER HEAD	1
			120250004-0001	GASKET, CYLINDER HEAD COVER	1
5	170440003-0001	INSULATOR, CARBURETTOR	170440003-0001	INSULATOR, CARBURETTOR	1


6	170430004-0001	GASKET, CARBURETTOR	170430004-0001	GASKET, CARBURETTOR	1
---	----------------	---------------------	----------------	---------------------	---

E-4 右曲轴箱盖 (RIGHT CRANKCASE COVER)




1	110600077-0037	COVER COMP, R. CRANKCASE	110600077-0037	COVER COMP, R. CRANKCASE	1
2	380140059-0002	BOLT, HEXAGONAL WITH FLANGE	380140059-0002	BOLT, HEXAGONAL WITH FLANGE	1
3	380140057-0001	BOLT, HEXAGONAL WITH FLANGE	380140057-0001	BOLT, HEXAGONAL WITH FLANGE	1
4	380140019-0003	BOLT, HEXAGONAL WITH FLANGE	380140019-0003	BOLT, HEXAGONAL WITH FLANGE	5
5	380840042-0001	SEAL	380840042-0001	SEAL	1
6	110700002-0003	GAUGE, OIL LEVEL	110700002-0003	GAUGE, OIL LEVEL	1
7	380650029-0001	OIL SEAL	380650029-0001	OIL SEAL	1
8	LX125-H	CLUTCH LEVER	381160024-0001	CLUTCH LEVER ASSY	1
			190810010-0002	CLUTCH LEVER	1
9	110620010-0001	GASKET, R. CRANKCASE COVER	110620010-0001	GASKET, R. CRANKCASE COVER	1
10	380140020-0001	BOLT, HEXAGONAL WITH FLANGE	380140020-0001	BOLT, HEXAGONAL WITH FLANGE	1
11	191230010-0001	CLUTSH CABLE STAND	191230010-0001	CLUTSH CABLE STAND	1

E-5 曲轴箱体 (CRANKCASE)




1	150290002-0001	SCREEN, OIL FILTER	150290002-0001	SCREEN, OIL FILTER	1
2	LX125-I	CRANKCASE COMP. , R&L	110080019-0008	CRANKCASE COMP. R	1
			110030027-0008	CRANKCASE COMP. L	1
3	380600012-0001	PIN KNOCK	380600012-0001	PIN KNOCK	2
4	380450018-0003	WASHER, DRAIN PLUG	380450018-0003	WASHER, DRAIN PLUG	1
5	110260003-0002	BOLT, DRAIN PLUG	110260003-0002	BOLT, DRAIN PLUG	1
6	LX125-J	CYLINDER STUD BOLT	110250008-0002	BOLT B, CYLINDER STUD	2
			110240010-0002	BOLT A, CYLINDER STUD	2
7	380950016-0001	CLAMP, BREATHER TUBE	380950016-0001	CLAMP, BREATHER TUBE	1
8	380140020-0002	BOLT	380140020-0002	BOLT	2
9	380140032-0001	BOLT	380140032-0001	BOLT	1
10		BOLT		BOLT	5
11	380740022-0001	TUBE, BREATHER	380740022-0001	TUBE, BREATHER	1
12	110100012-0001	GASKET, CRANKCASE	110100012-0001	GASKET, CRANKCASE	1

E-6 离合器 (CLUTCH)



1	500280038-0001	CLUTCH COMP	500280038-0001	CLUTCH COMP	1
			190730005-0001	ASLE SLEEVE, SEPARATING	1
			380070015-0005	NUT	4
			380630013-0001	BEARING, CLUTCH COVER	1
			190480004-0001	LIFT PLATE	1
			380550014-0001	WASHER	1
			190550010-0001	SPRING	4
			380480002-0001	WASHER	1
				CENTER PIECE	1
				FRICTION PLATE, DRIVE	5
				FRICTION PLATE, DRIVEN	4
				CLAMP PLATE	1
			190330014-0001	PRIMARY DRIVE GEAR	1
				COVER ASSY, CLUTCH	1
2	190780002-0001	PLATE,OIL SEPARATOR	190780002-0001	PLATE,OIL SEPARATOR	1
3	380070012-0005	BOLT,HEX.,M6*20	380070012-0005	BOLT,HEX.,M6*20	2


E-7 机油泵/机油滤清器(OIL PUMP/OIL FILTER COMP)



1	150010031-0001	OIL PUMP COMP	150010031-0001	OIL PUMP COMP	1
				BODY, OILPUMP	1
				COVER, OILPUMP	1
				GEAR, OIL PUMP	1
				ROTOR, OIL PUMP OUTER	1
				ROTOR, OIL PUMP INNER	1
				SPINDLE, OILPUMP	1
			381370001-0001	PIN	1
			380200006-0002	BOLT	2
			380600045-0001	PIN	1
				OBJECT	1
				PIN	2
2	380220027-0001	BOLT	380220027-0001	BOLT	2
3	380220032-0002	BOLT	380220032-0002	BOLT	1

4	150350002-0001	OIL FILTER COMP	150350002-0001	OIL FILTER COMP	1
			150490002-0001	SEAT, OIL FILTER	1
			380480002-0001	WASHER	1
			380810008-0001	NUT	1
			150540002-0001	GASKET, FINE OIL FILTER	1
			150360002-0001	COVER, FINE OIL FILTER	1
			380220009-0001	BOLT	4


E-8 磁电机/左曲轴箱盖 (GENERATOR/LEFT CRANKCASE COVER)



1	110400042-0054	COVER, L. CRANKCASE	110400042-0054	COVER, L. CRANKCASE	1
2	110420008-0001	GASKET, L. CRANKCASE COVER	110420008-0001	GASKET, L. CRANKCASE COVER	1
3	LX125-K	GENERATOR	270010024-0032	GENERATOR	1
			270020034-0001	FLYWHEEL COMP	1
			270100038-0050	STATOR COMP.	1
			380370011-0001	NUT	1
4	LX125-L	SPROCKET COMP, STARTING	380650056-0001	OIL SEAL	1
			193290001-0001	SPROCKET COMP, STARTING	1
			193270001-0001	CHAIN, STARTING	1
			380650054-0001	OIL SEAL	1
5	380840048-0001	O-RING	380840048-0001	O-RING	1
6	110310002-0003	DISK COVER	110310002-0003	DISK COVER	1
7	380840064-0001	O-RING	380840064-0001	O-RING	1
8	LX125-M	SMALL CAP EYEHOLE&BIG CAP EYEHOLE	110440001-0007	SMALL CAP EYEHOLE	1
			110430004-0006	BIG CAP EYEHOLE	1
			380840005-0001	O-RING	1
			380840026-0001	O-RING	1
9	380600012-0001	PIN, KNOCK	380600012-0001	PIN, KNOCK	3
10	380140017-0005	BOLT	380140017-0005	BOLT	4


11	380140020-0003	BOLT	380140020-0003	BOLT	1
12	380140169-0002	BOLT	380140169-0002	BOLT	2
13	380140030-0005	BOLT	380140030-0005	BOLT	1
14	380140068-0004	BOLT	380140068-0004	BOLT	1

E-9 活塞/曲轴 (PISTON/CRANKSHAFT COMP)



1	LX125-N	PISTON ASSY.	130070019-0001	PISTON RING	1
			380560006-0001	CIRCLIP, PISTON PIN	2
			130060019-0001	PISTON PIN	1
			130030024-0001	PISTON	1
2	130140027-0001	CRANKSHAFT COMP	130140027-0001	CRANKSHAFT COMP	1
			130350002-0001	CRANK PIN	1
			380630034-0002	NEEDLE BEARING	1
			130150004-0001	CONNETING ROD	1
			380630022-0001	CRANKSHAFT ROLLING BEARING	2
			130260018-0001	CRANKSHAFT	1
			130210004-0001	CRANKSHAFT	1
			380620002-0001	SEMI CIRCLAR KEY	1
				CRANKSHAFT TIMING GEAR	1
				DRIVEN GEAR, PRIMARY	1

E-10 主轴\副轴(MAINSHAFT\COUNTERSHAFT ASSY)




			500290010-0001	TRANSMISSION ASSY	1
			191250005-0001	MAINSHAFT COUNERSHAFT	1
			191390005-0001	COUNERSHAFT MAINSHAFT	1
			191260005-0001	MAINSHAFT	1
			191400005-0001	COUNTERSHAFT	1
			191420003-0001	GEAR SOUNTERSHAFT FIRST	1
			191440004-0001	GEAR, COUNTERSHAFT SECOND	1
			191290004-0001	GEAR, MAINSHAFT THIRD	1
			191300004-0001	GEAR, MAINSHAFT FOURTH	1
			191460004-0001	GEAR, COUNTERSHAFT FHIRD	1
			191480004-0001	GEAR, COUNTERSHAFT FOURTH	1
			191280004-0001	GEAR, MAINSHAFT SECOND	1
			380500003-0002	WASHER, SPLINE-A17mm	2
			380540003-0001	FLAT	2
			380540018-0001	FLAT	1
			380630013-0001	NEEDLE BEARING	1

1	LX125-O	TRANSMISSION ASSY. AND DRUM COMP., GEARSHIFT	380630033-0001	NEEDLE BEARING	1
			380540023-0001	FLAT	1
			380540020-0001	FLAT	1
			380500004-0001	WASHER, SPLINE	2
			380550018-0001	CIRCLIP	2
			380820085-0001	BUSHING	1
			380630002-0001	BEARING, RADIAL BALL	1
			192060065-0001	DRUM COMP, GEARSHIFT	1
			380070015-0001	BOLT	1
			192100003-0001	SHIFT CAM	1
			192110003-0001	PLATE, GEARSHIFT DRUM	
			380600015-0001	PIN	2
			380600014-0001	PIN	3
			192120035-0001	FORK, GEARSHIFT	2
			192090001-0001	PINCHCOCK	2
			192140001-0001	PIN	2
			192080019-0001	DRUM, GEARSHIFT	1
			270720008-0001	CONTACTOR, GEAR INDICATOR	1
			380190061-0001	BOLT	1
2	380650061-0001	OIL SEAL	380650061-0001	OIL SEAL	1
3	LX125-P	SPROCKET,DRIVE	191600012-0007	SPROCKET, DRIVE	2
			191610002-0001	PLATE, FIXING, DRIVE SPROCKET	1
			380070004-0001	BOLT	2
4	192320027-0001	ARM COMP.GEARSHIFT	192320027-0001	ARM COMP. GEARSHIFT	1
			192420002-0001	ARM GEARSHIFT	1
			192340018-0001	SPINDLE COMP. GEARSHIFT	1
			380820087-0001	COLLAR	1
			381160015-0001	SPRING, GEARSHIFT RETURN	1
			380610016-0001	PIN	1


			380650031-0001	OIL SEIL	1
5	LX125-Q	INDICATOR, GEAR	270650020-0001	INDICATOR	1
			270740001-0001	INDICATOR PRESSURE	1
			380140026-0003	BOLT, M6×10	1
6	LX125-R	STOPPER COMP.,GEARSHIFT DRUM	192190004-0001	STOPPER COMP.	1
			381160028-0001	SPRING	1

E-11 链条张紧器 (CAM CHAIN/TENSIONER)




1	LX125-S	SPROCKET AND CHAIN TRANSMISSION ASSY	140610030-0001	CHAIN, CAM	1
			141210002-0001	ROLLER, CAM CHAIN TENSIONER	1
			140580005-0001	SPROCKET, CAM	1
			141240004-0001	ROLLER COMP. , CAM CHAIN GUIDE	1
			140590001-0002	BOLT, KNOCK	3
			380450056-0001	WASHER	1
			141270002-0004	PIN, CAM CHAIN GUIDE ROLLER	1
			150150001-0001	SPROCKET, OIL PUMP	1
2	LX125-T	CHAIN TENSIONER ASSY.	380190061-0001	SPINDLE, CAM CHAIN GUIDE SPROCKET	1
			141160001-0001	ARM COMP. , CAM CHAIN TENSIONER	1
			141200001-0001	PIVOT, CAM CHAIN TENSIONER	1
				HEAD, CAM CHAIN TENSIONER PUSH ROD	1
			141080001-0001	ROD COMP. , CAM CHAIN TENSIONER PUSH	1
			381150030-0001	SPRING, CAM CHAIN TENSIONER	1
			380450054-0001	WASHER, SEALING	1
			110260004-0001	BOLT, SEALING	1

E-12 启动机构(KICK STARTER SPINDLE)




1	193300009-0001	SPINDLE COMP,KICK STARTER	380570004-0001	CIRCLIP	1
			193470002-0001	RETAINER, KICK SPRING	1
			193340003-0001	SPRING, KICK STARTER	1
			380540021-0001	WASHER	1
			380550010-0001	CIRCLIP	2
			193360001-0001	RATCHET WHEEL GUIDE STRIP	1
			193350003-0001	SPRING, STARTER PINION FRICTION	1
			193330003-0001	RATCHET, STARTER	1
			380540007-0001	WASHER, THRUST, 20mm	2
			193320004-0001	PINION, KICK STARTER	1
			193310005-0001	SPINDLE, KICK STARTER	1
			193300009-0001	SPINDLE COMP, KICK STARTER	1

E-13 起动装置 (KICK STARTER SPINDLE)



1	270350005-0026	MOTOR ASSY. , STARTER	270350005-0026	MOTOR ASSY. , STARTER	1
				MOTOR, STARTER	1
				CUSHION	1
				GASKET	1
				GEAR	1
				BEARING	1
				END CAP	1
				DRIVING CHAIN WHEEL	1
				CIRCLIP	1
			270390003-0001	HARNESS, STARTING MOTOR	1
				SCREW	4
				WASHER	4

E-14 化油器/进气管(CARBURETOR COMP/PIPE IN)



1		CARBURETOR		CARBURETOR	1
2		PIPE,IN		PIPE,IN	1
3		WASHER		WASHER	1
4		INLET PIPE WASHER		INLET PIPE WASHER	1
5		CARBURETOR WASHER		CARBURETOR WASHER	1
6		BOLT		BOLT	2
7		BOLT		BOLT	2