




T-REX 125 ENGINE PARTS LIST



序号 S.N	PARTS NO.	DESCRIPTION (CHINESE)	DESCRIPTION (ENGLISH)	图片 Picture	QTY
-----------	-----------	--------------------------	--------------------------	---------------	-----


E-1 气缸头/气缸体(CYLINDER HEAD/CYLINDER BODY)



1	120080258-0003	气缸头	HEAD. CYLINDER		1
2	120020055-0004	气缸体	CYLINDER ASSY		1
3	120150022-0001	气缸头密封	GASKET,CYLINDER HEAD		1
4	120050020-0001	气缸体密封	GASKET,CYLINDER		1
5	380820090-0001	衬套	COLLAR		1

6	380840047-0001	密封圈	RECTANGULAR RIN		1
7	380600028-0001	定位销	PIN		1
8	380180031-0004	双头螺栓	STUD		1
9	380040003-0004	十字槽凹	BOLT		1
10	380600029-0001	定位销	PIN		2
11	380820089-0001	衬套	WASHER		1
12	380840045-0001	密封圈	O-RING		1
13	380840046-0001	密封圈	O-RING		1
14	380040007-0003	十字槽凹	BOLT		1
15	120060005-0001	缸体减震	DAMPING BUSHING		2
16	120060006-0001	缸体减震	DAMPING BUSHING		1


E-2 气缸头盖 (COVER,CYLINDER HEAD)



1	270960004-0001	火花塞	SPARK PLUG		1
2	120280003-0001	气门盖	VALVE CAP		2
3	380840132-0001	密封圈	O-RING		2
4	380140066-0005	六角头法	BOLTM		1
5	380140015-0006	六角头法	BOLTM		2
6	380450048-0001	平垫圈	GASKET		1
7	120350004-0002	气缸头右	COVER,CYLINDER HEAD		1
8	120370001-0001	气缸头右	GASKET,R.CYLINDER HEAD SIDE COVER		1
9	380330017-0005	盖形螺母	NUT,CYLINDER HEAD COVER		4
10	380450087-0001	平垫圈	GASKET		3
11	380450088-0001	平垫圈	GASKET		1
12	120230018-0001	气缸头盖	GOVER,CYLINDER HEAD		1

13	120250004-0001	气缸头盖	GASKET,CYLINDER HEAD COVER		1
14	120310003-0001	气缸头左	GASKET,L.CYLINDER HEAD SIDE COVER		1
15	120300009-0006	气缸头左	COVER,L.CYLINDER HEAD SIDE		1


E-3 气门组件 (CAMSHAFT/VALVE)



1	140020004-0001	凸轮轴组	CAMSHAFT COMP		1
2	140200001-0001	气缸头止	REDUCING VALVE		1
3	140510002-0001	气门摇臂	SHAFT,VALVEROCKER ARM		2
4	140490003-0001	气门调节	NUT,TAPPET ADJUSTING		2
5	140480002-0001	气门调节	SCREW,TAPPET ADJUSTING		2
6	140450003-0001	气门摇臂	ARM,VALVE ROCKER		2
7	140390002-0001	气门锁夹	COTTER,VALVE		4
8	140380002-0001	气门弹簧	RETAINER,VALVE INNER SPRING		2


9	140340002-0001	气门内弹	SPRING,VALVE INNER		2
10	140350002-0001	气门外弹	SPRING,VALVE OUTER		2
11	140370002-0001	气门外弹	SEAT,VALVE OUTER SPRING		2
12	140400002-0001	挡油罩	SEAL, VALVE STEM		2
13	140300005-0001	进气门	VALVE,IN		1
14	140310005-0001	排气门	CAMSHAFT COMP		1
15	140330002-0001	气门弹簧	SPRING ASSY,VALVE		2
16	500550005-0001	气门套件	VALVE SET		1
17	500730002-0001	气门弹簧	VALVE SPRING SEAT CLAMP SET		2

E-4 右曲轴箱盖 (RIGHT CRANKCASE COVER)



1	110600077-0037	右曲轴箱盖	COVER COMP,R.CRANKCASE		1
2	380140059-0005	六角头法	BOLT,HEXAGONAL WITH FLANGE		1
3	380140057-0005	六角头法	BOLT,HEXAGONAL WITH FLANGE		1
4	380140019-0006	六角头法	BOLT,HEXAGONAL WITH FLANGE		5
5	380840006-0001	密封圈	SEAL		1
6	110700002-0003	机油尺	GAUGE,OIL LEVEL		1
7	380650029-0001	油封	OIL SEAL		1
8	381160024-0001	扭簧	CLUTCH LEVER ASSY		1
9	190810010-0002	离合器操纵杆	CLUTCH LEVER		1
10	110620010-0001	右曲轴箱盖	GASKET,R.CRANKCASE COVER		1
11	380140020-0003	六角头法	BOLT,HEXAGONAL WITH FLANGE		1
12	191230010-0002	离合器拉杆	CLUTSH CABLE STAND		1
13	380840083-0001	密封圈	SEAL		2
14	380940021-0004	线夹	CLAMP		1


E-5 曲轴箱体 (CRANKCASE)



1	150290002-0001	机油滤网	SCREEN,OIL FILTER		1
2	110080019-0001	右曲轴箱	CRANKCASE COMP.R		1
3	380600001-0001	定位销	PIN KNOCK		2
4	380450018-0003	平垫圈	WASHER,DRAIN PLUG		1
5	110260003-0006	密封螺塞	BOLT,DRAIN PLUG		1
6	110250008-0001	双头螺栓	BOLT B,CYLINDER STUD		2
7	110240010-0001	双头螺栓	BOLT A,CYLINDER STUD		2
8	380940501-0002	管夹	CLAMP,BREATHER TUBE		1
9	380140032-0005	六角头法	BOLT		2
10	380140020-0003	六角头法	BOLT		1
11	380140057-0005	六角头法	BOLT		3
12	380740022-0001	通气管	TUBE,BREATHER		1


13	110100012-0001	曲轴箱密封	GASKET,CRANKCASE		1
14	110030166-0003	左曲轴箱	CRANKCASE COMP.L		1
15	500270155-0002	曲轴箱体	CRANKCASE COMP. SET		1
16	380950016-0001	管夹	TUBE CLIP		1

E-6 离合器 (CLUTCH)



1	500280038-0001	离合器套	CLUTCH COMP		1
2	190730005-0001	推杆	ASLE SLEEVE,SEPARATING		1
3	380070015-0006	六角头螺	NUT		4
4	380630024-0001	滚动轴承	BEARING,CLUTCH COVER		1
5	190480004-0001	升板	LIFT PLATE		1
6	380610008-0001	圆螺母	NUT,ROUND		1
7	190550010-0001	离合器弹	SPRING		4
8	380480001-0001	蝶形垫圈	WASHER		1
9	190400011-0001	离合器中	CENTER PIECE		1
10	190430004-0001	主动摩擦	FRICTION PLATE,DRIVE		5
11	190460010-0001	从动摩擦	FRICTION PLATE,DRIVEN		4
12	190470019-0001	压板	CLAMP PLATE		1
13	190330017-0001	离合器外	PRIMARY DRIVE GEAR		1
14	190030006-0001	初级主动	COVER ASSY,CLUTCH		1
15	190780002-0001	隔油盘组	PLATE,OIL SEPARATOR		1
16	380070012-0005	六角头螺	BOLT,HEX.,M6*20		2


E-7 机油泵/机油滤清器(OIL PUMP/OIL FILTER COMP)



1	150010031-0001	机油泵部	OIL PUMP COMP		1
8	380600180	圆柱销	PIN		1
9	380200061-0004	十字槽沉头螺栓	BOLT		2
10	380200024-0003	十字槽沉头螺栓	BOLT		1
11	380200006-0002	十字槽盘头螺栓	BOLT		2
12	380600011-0001	圆柱销	PIN		1
13	380570018-0001	开口挡圈	OBJECT		1
14	380600012-0001	定位销	PIN		2
15	150350002-0001	机油精滤器	OIL FILTER COMP		1
16	150490002-0001	机油滤清器座	SEAT, OIL FILTER		1
17	380480002-0001	碟形垫圈	WASHER		1
18	380810019-0001	圆螺母	NUT		1
19	150540002-0001	机油滤清器垫圈	GASKET, FINE OIL FILTER		1

20	150360002-0001	机油精滤器	COVER, FINE OIL FILTER		1
21	380220009-0001	十字槽沉头螺栓	BOLT		4


E-8 磁电机/左曲轴箱盖 (GENERATOR/LEFT CRANKCASE COVER)



1	380840055-0001	密封圈	O-RING		1
2	110310002-0003	盘盖	DISK COVER		1
3	380600012-0001	定位销	PIN,KNOCK		3
4	380840064-0001	密封圈	O-RING		1
5	380140017-0005	六角头法	BOLT		2
6	380140030-0005	六角头法	BOLT		1
7	380650054-0001	油封	OIL SEAL		1
8	140910002-0001	链条张紧	TENSION SLIDER, CHAIN		1
9	141000002-0001	链条导向	SLIDER, CHAIN		1
10	193270001-0001	启动链条	CHAIN,STARTING		1
11	193170006-0001	电起动从	SPROCKET COMP,STARTING		1
12	380650056-0001	油封	OIL SEAL		1
13	193290001-0001	电起动从	PLATE,SPROCKET SETTING		1
14	380140026-0003	六角头法	BOLT,HEXAGONAL WITH FLANGE		1


15	270020034-0001	磁电机转	FLYWHEEL COMP		1
16	270010024-0029	磁电机组	GENERATOR		1
17	270100038-0050	磁电机锭	STATOR COMP.		1
18	380370011-0001	六角法兰	NUT		1
19	110400042-0054	左前盖	COVER,L.CRANKCASE		1
20	110440001-0007	视孔盖	EYEHOLE		1
21	380840026-0001	密封圈	O-RING		1
22	380840005-0001	密封圈	O-RING		1
23	110430001-0006	左装饰盖	BIG CAP EYEHOLE		1
24	380140169-0002	六角头法	BOLT		1
25	110480005-0001	压线板	PRESSING PLATE FOR CABLE		1
26	380200060-0003	十字槽盘	SCREW		1
27	110480009-0003	压线板	PRESSING PLATE FOR CABLE		1
28	380140002-0002	六角头法	BOLT		1
29	110500004-0001	胶塞	PLUG		1
30	380140015-0003	六角头法	BOLT		2
31	380200006-0005	十字槽盘	SCREW		2
32	380140068-0004	六角头法	BOLT		1
33	380140020-0003	六角头法	BOLT		1
34	380450021-0001	平垫圈	GASKET		1
35	380940021-0004	线夹	CLAMP		1
36	380940002-0004	线夹	CLAMP		1

E-9 活塞/曲轴 (PISTON/CRANKSHAFT COMP)



1	130070006-0001	活塞环组	PISTON RING		1
2	380560006-0001	钢丝挡圈	CIRCLIP,PISTON PIN		2
3	130060019-0001	活塞销	PISTON PIN		1
4	130030024-0001	活塞	PISTON		1
5	130140027-0001	曲柄连杆	CRANKSHAFT COMP		1
6	130350002-0001	曲柄销	CRANK PIN		1
7	380630034-0002	滚针轴承	NEEDLE BEARING		1
8	130150004-0001	连杆	CONNETING ROD		1
9	380630022-0001	曲轴滚动轴承	CRANKSHAFT ROLLING BEARING		2
10	130260018-0001	右曲柄	CRANKSHAFT		1
11	130210017-0001	左曲柄	CRANKSHAFT		1
12	380620002-0001	半圆键	SEMI CIRCLAR KEY		1
13	130230006-0001	正时主动齿轮	CRANKSHAFT TIMING GEAR		1
14	150150008-0001	油泵主动齿轮	DRIVEN GEAR, PRIMARY		1


E-10 主轴\副轴(MAINSHAFT\COUNTERSHAFT ASSY)



1	500290085-0001	主副轴套	TRANSMISSION ASSY.		1
2	191300004-0001	主轴四档	GEAR,MAINSHAFT FOURTH		1
3	380500003-0002	花键垫圈	WASHER,SPLINE		2
4	380550018-0001	弹性挡圈	CIRCLIP,EXTERNAL		2
5	191290004-0001	主轴三档	GEAR,MAINSHAFT THIRD		1
6	191280004-0001	主轴二档	GEAR,MAINSHAFT SECOND		1
7	191200005-0001	主轴	MAINSHAFT,TRANSMISSION		1
10	380630002-0001	轴承	BEARING		1
9	380630013-0001	轴承	BEARING		1
	380630033-0001	轴承	BEARING		1
11	380540027-0001	轴肩挡圈	CIRCLIP		1
12	191480004-0001	副轴四档	GEAR,COUNTERSHAFT FOURTH		1
13	380340025-0001	轴肩挡圈	CIRCLIP		1
14	191460004-0001	副轴三档	GEAR,COUNTERSHAFT THIRD		1
15	380300007-0001	花键垫圈	WASHER,SPLINE		1
16	380330010-0001	弹性挡圈	CIRCLIP,EXTERNAL		2
17	191440004-0001	副轴二档	GEAR,COUNTERSHAFT SECOND		1
18	380300006-0001	花键垫圈	WASHER		1
19	380820590-0001	衬套	BUSH		1
20	191420005-0001	副轴一档	GEAR,COUNTERSHAFT LOW		1
21	191400053-0001	副轴	COUNTERSHAFT		1
22	380650061-0001	油封	OIL SEAL		1
23	191600012-0009	副轴主动锥	SPROCKET,DRIVE		1
24	191610002-0001	副轴主动锥	PLATE,FIXING,DRIVE SPROCKET		1
25	380070004-0001	六角头螺	BOLT HEX		2


26	191250005-0001	主轴部件	MAINSHAFT, TRANSMISSION		1
27	191390087-0001	副轴部件	COUNTERSHAFT, TRANSMISSION		1

E-11 链条张紧器 (CAM CHAIN/TENSIONER)




1	140610030-0001	正时链条	CHAIN,CAM		1
2	380190061-0001	内六角螺栓	SPINDLE,CAM CHAIN GUIDE SPROCKET		1
3	141160001-0001	链条张紧臂	ARM COMP.,CAM CHAIN TENSIONER		1
4	141210002-0001	链条张紧轮	ROLLER,CAM CHAIN TENSIONER		1
5	140580005-0001	正时从动链轮	SPROCKET,CAM		1
6	141240004-0001	链条导向轮	ROLLER COMP.,CAM CHAIN GUIDE		1
7	140590001-0002	正时螺栓	BOLT,KNOCK		3
8	380450056-0001	平垫圈	WASHER		1
9	141270002-0004	导向轮销轴	PIN, CAM CHAIN GUIDE ROLLER		1
10	141210003-0001	链条张紧链轮	SPROCKET,OIL PUMP		1
11	141200001-0001	张紧臂芯轴	PIVOT,CAM CHAIN TENSIONER		1
12	141100001-0001	链条张紧头	HEAD,CAM CHAIN TENSIONER PUSH ROD		1
13	141080001-0001	链条张紧杆	ROD COMP.,CAM CHAIN TENSIONER PUSH		1
14	381150030-0001	压簧	SPRING,CAM CHAIN TENSIONER		1
15	380450054-0001	平垫圈	WASHER,SEALING		1
16	110260004-0004	密封螺塞	BOLT,SEALING		1
17	380460003-0004	弹性垫圈	SPRING WASHER		1


E-12 启动机构(KICK STARTER SPINDLE)




1	380550071-0001	开口挡圈	CIRCLIP		1
2	193470002-0001	复位弹簧	RETAINER,KICK SPRING		1
3	193340003-0001	起动轴复位	SPRING,KICK STARTER		1
4	380540021-0001	轴肩挡圈	WASHER		1
5	380550010-0001	挡圈	CIRCLIP		2
6	193360001-0001	棘轮弹簧	RATCHET WHEEL GUIDE STRIP		1
7	193350003-0001	棘轮弹簧	SPRING,STARTER PINION FRICTION		1
8	193330003-0001	起动棘轮	RATCHET,STARTER		1
9	380540007-0001	止推垫圈	WASHER,THRUST,20mm		2
10	193320004-0001	起动轴齿	PINION,KICK STARTER		1
11	193310005-0001	起动轴	SPINDLE,KICK STARTER		1
12	193300009-0001	起动轴部	SPINDLE COMP,KICK STARTER		1


E-13 变速装置 GEARSHIFT DRUM



1	192320027-0001	换档臂部	ARM COMP.GEARSHIFT		1
2	192420001-0001	换档臂主体	ARM GEARSHIFT		1
3	192340028-0001	换档轴	SPINDLE COMP.GEARSHIFT		1
4	380820087-0001	衬套	COLLAR		1
5	381160015-0001	扭簧	SPRING,GEARSHIFT RETURN		1
6	192310001-0001	换档臂定位销	PIN,SHIFT RETURN SPRING		1
7	380650031-0001	油封	OIL SEIL		1
8	192060065-0001	变速鼓部	DRUM COMP,GEARSHIFT		1
9	380070015-0001	六角头螺	BOLT		1
10	192100003-0001	五星拨板	SHIFT CAM		1


11	192110002-0001	变速鼓垫	WASHER PLATE, GEARSHIFT DRUM		1
12	380600028-0001	定位销	PIN		2
13	380600029-0001	定位销	PIN		3
14	192120035-0001	变速拨叉	FORK,GEARSHIFT		2
15	192090001-0001	弹簧夹	PINCHCOCK		2
16	192140001-0001	拨叉销	PIN		2
17	192080019-0001	变速鼓	DRUM,GEARSHIFT		1
18	192190004-0001	止动板组	STOPPER COMP.,GEARSHIFT DRUM		1
19	381160028-0001	扭簧	SPRING,SHIFT DRUM STOPPER		1

E-14 起动装置 (KICK STARTER SPINDLE)



1	270350005-0026	起动电机	MOTOR ASSY.,STARTER		1
13	270390003-0001	起动电机	HARNESS,STARTING MOTOR		1

E-15发动机全套密封垫及油封 (All the engine seals, gaskets and o-rings)



1	LX125-A	发动机全套油封12	ENGINE OIL SEAL SET 125CC		1
2	LX125-B	发动机全套密封垫12	ENGINE GASKETS SET 125CC		1