


T-REX125(ST125-11) E4 VEHICLE PARTS PRICE LIST

No.	Part number	Part name(ENGLISH)	Part name(CHINESE)	QTY. on each bike
发动机部分: ENGINE				
				
1	11000-22H50	125cc Engine	125发动机	1
2	11001-22H10-008	Left Side Cover, Engine	左后边盖	1
3	26300-Z1000	Kick Starter	启动杆	1
3.1	GB/T 5783 M6X25-Zn	M6×25 Bolt	M6×25六角螺栓	1
4	25600-18H00	Shift Pedal Assy	变档杆总成	1
5	GB/T 16674 M6X28-Zn	M6×28 Bolt	M6×28法兰螺栓	2
6	GB/T70.1 M6X20-Zn.DJ	M6X20 Bolt	M6X20内六角圆柱头螺钉	1


电喷系统: FUEL INJECTION SYSTEM



1	11011-15AD0	Intake Manifold	进气管	1
2	81115-27A00	M6X25 Bolt	M6X25防拆螺栓	2
3	33920-16H00	Fuel Injector	喷油器	1
4	33921-16H00	Oil Nozzle	油嘴帽	1
5	33922-15A00	Pressing Plate,Oil Nozzle	油嘴压板	1
6	GB/T70.1 M5X12-304	M5×12 Bolt	M5×12内六角圆柱头螺钉	1
7	33910-22H00	ECU	ECU	1
7,1	33913-16H00	Plug, ECU	ECU堵头	1
8	GB70.2-2000 M5X12-304	Bolt	M5X12内六角盘头螺栓	4
9	13510-15A00	Throttle Valve	节气阀体	1
10	13520-15A00	Throttle Valve Cap	节气门体盖	1
11	13530-15A00	Connecting Pipe/Clip, Pipe Inlet	进气管连接管/卡箍	1
12	44420-16H00	Quick Fuel Hose	快接油管	1
13	33940-16H00-L	Electromagnetic Plunger Pump	电磁柱塞油泵	1
14	41129-16H00	Electromagnetic Pump Holder	电磁油泵支架	1
15	GB/T16674 M6X12-Zn.DJ	M6×12 Flange Bolt	M6×12法兰螺栓	1
16	44127-22H00	Vacuum Fuel Pump	负压油泵	1
17	44128-22H00	Bracket, Vacuum Fuel Pump	负压油泵支架	1
18	GB/T16674 M6X16-Zn.DJ	M6×16 Flange Bolt	M6×16法兰螺栓	3
19	44400-15A00	Gas Filter	油滤	1
20	44401-17H00	Holder, Oil Filter	油滤支架	1
21	36612-16H10	ECU Connection Line 2	ECU连接线2	1
22	36611-16H00	ECU Connection Line 1	ECU连接线1	1


23	33930-16H00	Lambda Sensor	氧传感器	1
24	33931-16H00	Plug In Unit Holder,Lambda Sensor	氧传感器插件支架	1
25	33400-16H00	Ignition Coil	高压包	1
26	33911-16H00	OBD connection line	OBD连接线	1
27	33990-16H00	Diagnostic instrument	故障诊断仪	1
28	33912-16H00	OBD Bluetooth adapter	OBD蓝牙适配器	1

车架：FRAME



1	41100-22H50	Frame Comp (Color)	车架	1
2	09112-14A10	M8×120 Bolt	M8×120吊发轴	1
3	09113-Z1000	M8×112 Bolt	M8×112吊发轴	1
4	GB/T 6187.1 M8-Zn.DJ	M8 Flange Nut	M8法兰自锁螺母	2

单撑：SIDE STAND



1	42310-22H00	Side Stand	单撑组件	1
2	42312-Z1000	Outer Spring, Side Stand	单撑外弹簧	1
3	42321-Z1000	Inner Spring, Side Stand	单撑内弹簧	1
4	42311-23H00	Bolt, Side Stand	单撑螺栓	1
5	42313-Y1000	Switch, Side Stand	单撑熄火开关	1
6	GB/T16674 M6X16-A2-70-304	M6X16 Flange Bolt	M6X16法兰螺栓	1

搁脚部分：FOOTREST ASSY



1	43510-22H10	Front Footrest Assy	前脚踏总成	1
2	GB/T16674 M8X16-Zn.DJ	M8X16 Flange Bolt	M8X16法兰螺栓	4
3	GB/T16674 M8X16-Zn.DJ	M8X16 Flange Bolt	M8×16法兰螺栓	2
4	43530-22H00	Stop Collar, Brake Pedal	踏杆限位胶套	1
5	43730-21H00	Rear Footrest Pedal Assy	后脚踏组件	2

电器部分： ELECTRICAL COMPONENTS




1	36610-22H05	Wiring Harness	导线束	1
2	32800-16H00	Rectifier Assy	稳压器	1
3	GB/T70.1 M6X25-Zn.DJ	Screw	内六角圆柱头螺钉	2
4	31800-Y1000	Start Relay	启动继电器	1
5	31810-17H00	Bracket, Start Relay	启动继电器支架	1
6	38500-Y1000	Horn Assy	喇叭	1
7	GB/T16674 M6X12-Zn.DJ	M6×12 Flange Bolt	M6×12法兰螺栓	2
8	38620-23H00	Flash Relay	闪光器	1
9	37100-22H00	Lock Assy	套锁总成	1
10	37152-21H00	M8×30 Bolt	M8×30防拆螺栓	2
11	33610-14A00	Battery	12V4Ah蓄电池	1
12	41522-14A00	Band, Battery	蓄电池攀带	1
13	33620-22H00	Holder, Battery	蓄电池支架	1
14	GB/T16674 M6X12-Zn.DJ	M6×12 Flange Bolt	M6×12法兰螺栓	2

仪表 :SPEEDOMETER




1	34100-22H30	LCD Speedometer Assy	液晶仪表	1
2	35608-17H00	Rubber Ring	橡胶圈	3
3	61412-28H00	Step Spacer	台阶衬套	3
4	GB/T 6177 .1 M6-Zn.DJ	M6 Flange Nut	M6法兰防滑螺母	3
5	34110-22H30	Mounting Bracket, Speedometer	仪表安装支架	1
6	GB/T16674 M6X10-Zn.DJ	M6×10 Flange Bolt	M6×10法兰螺栓	2
7	34220-22H00	Speedometer Mounting Holder	仪表安装座	1
8	34231-21H00	Cushion Ring	缓冲圈	2
9	34233-21H00	Bushing, Cushion Ring	缓冲圈衬套	2
10	59260-21H00	Clamp	上部左固定卡	1
11	34232-21H00	Bolt	马蹄螺栓	2
12	GB/T 6187.1 M6-Zn.DJ	M6 Flange Nut	M6法兰自锁螺母	2



灯具 : LAMP




1	35100-22H20	Headlamp Assy (with LED DRL)	日行车前大灯	1
1.1	35120-21H00	Ring, Headlamp Lens	大灯圈	1
1.2	35115-29A00	Bulb, Headlamp	HS1大灯泡	1
1.3	37910-17H00	LED Controller	LED控制器	1
2	GB/T 820 M5X16-Zn.DJ	Screw	十字槽半沉头螺钉	2
3	35100-21H00	Headlamp Assy	前大灯	1
3,1	35107-Y1000	Bulb, Headlamp	大灯泡	1
3,2	35106-Y1000	Bulb, position	位置灯泡	1
4	35131-21H00	Housing, Headlamp	大灯灯壳	1
5	35122-14A00	Cushion	大灯罩缓冲垫	2
6	GB/T 70.2-2000 M8X20-304	M8X20 Flange Bolt	M8X20内六角螺栓	2
7	GB/T6187.2 M8-Zn.DJ	M8 Flange Nut	M8法兰自锁螺母	2



1	51540-21H00	Headlamp Holder, Lh	左大灯支架	1
2	51530-21H00	Headlamp Holder, Rh	右大灯支架	1
3	51556-21H00	Cushion Ring	缓冲胶圈	4
4	35210-17H40	LED Signal Lamp Assy, Lh	左转向灯	2
5	35310-17H40	LED Signal Lamp Assy, Rh	右转向灯	2
5.1	GB/T 6177 .1 M10×1.25-S14-Zn.DJ	M10 Nut	M10法兰防滑螺母	4



1	35710-22H00	Tail Lamp Assy	尾灯总成	1
1.1	35711-Y1000	Bulb, Tail Lamp	尾灯灯泡	1
2	GB/T 97.1 6-Zn.DJ	Φ6 Washer	Φ6平垫圈	2
3	GB/T 6177.1 M6-Zn.DJ	M6 Nut	M6法兰螺母	2
4	35914-21H00	Cushion, Rear Lamp	缓冲垫	1
5	35912-21H00	Support, Rear Lamp	尾灯座	1
6	Q/DPT-6X16-304	M6×16 Screw	M6×16加大盘头螺钉	2



1	38110-Y1010	Side Reflector	前反射器(E)	2
2	38111-22A00	Bracket,Side Reflector	前反射器支架	2
3	38160-Y1000	Rear Reflector	后反射器(E)	1
4	GB/T 93 5-Zn.DJ	Φ5 Spring Washer	Φ5弹垫圈	1
5	GB/T 96 5-Zn.DJ	Φ5 Washer	Φ5大垫圈	1
6	GB/T 6170 M5-Zn.DJ	M5 Hex Nut	M5六角螺母	1

手把开关: HANDLE SWITCHES



1	37300-21H01	Left Handle Switch	左手把开关	1
2	37200-22H00	Right Handle Switch	右手把开关	1
3	57211-21H00	Grip, Lh	左把套	1
4	57110-21H00	Grip, Throttle	油门胶套	1
5	57500-21H00	Clutch Lever Assy	离合闸把总成	1
5.1	57511-21H00	Lever, Clutch	离合手柄	1

方向把: HANDLE BAR




1	56110-22H00	Handlebar	方向把	1
2	56211-21H00	Handlebar Holder	上把手座	2
3	GB/T16674 M8X35-A2-70-304	M8×35 Flange Bolt	M8×35法兰螺栓	4
4	56121-21H10	Balance Weight	平衡块	2

前叉 : FRONT FORK




1	51311-21H00	Steering Head	上联板	1
2	51612-Z1000-304	Washer	大垫片	1
3	51633-Z1000	Steering Nut	方向柱顶螺母	1
4	51410-21H00	Steering Stem	下联板组件	1
5	51615-Y1000	Steering Locking Nut	转向轴锁紧螺母	1
6	51614-Y1000	Dust Seal	防尘垫片	2
7	32005 GB/T 297-94	Needle Bearing	圆锥滚针轴承	2
8	GB/T16674 M8X35-Zn.DJ	M8×35 Flange Bolt	M8×35法兰螺栓	2
9	GB/T16674 M10X1.25X50-Zn.DJ	M10×50 Flange Bolt	M10×50法兰螺栓	2
A	51100-22H00	Front Shock Absorber Assy.	前左、右减震器总成	1
10	51150-22H00	Shock Absorber, Front, Lh	左前减震器	1
11	51160-22H00	Shock Absorber, Front, Rh	右前减震器	1
11,1	51170-22H00	Oil Seal	前减油封	2
11,2	51180-21H00	Seal Cap	前减防尘罩	2

后平叉 后减震: REAR SWING ARM & REAR SHOCK ABSORBER




A	61000-22H10	Swing Arm Comp	后平叉组件	1
1	61100-22H10	Swing Arm	铁平叉	1
2	61277-22H00	Need Bearing	后平叉滚针轴承	2
3	61275-22H20	Bushing, Swing Arm	后平叉轴套	2
4	61222-22H10	Dust Hood	后平叉防尘罩	2
5	61211-22H10	Axle, Swing Arm	后平叉轴	1
6	GB 6187.2 M14X1.5-Zn.DJ	M14 Flange Nut	M14法兰自锁螺母	1
7	62100-22H00	Rear Shock Absorber Assy	后减震器	2
8	41148-21G00	Φ10 Washer	Φ10大垫圈	4
9	GB/T 97 12-Zn.DJ	Φ12 Washer	Φ12平垫	2
10	GB/T 923 M10X1.25-AZ-70-304	M10 Cap Nut	M10盖形螺母	4

前轮: FRONT WHEEL




A	55000-22H30	Front Wheel Assy	前轮总成	1
1	55700-22H20	Tire	21×7-10外胎	1
2	55501-22H00	Valve	气门嘴	1
3	55550-22H00	Rim, Front Wheel	前轮圈	1
4	GB/T 5783 M8X25-Zn.DJ	Hex Bolt	六角螺栓	4
5	GB/T 97.1 8-Zn.DJ	Φ8 Washer	Φ8平垫圈	4
6	GB/T 93 8-Zn.DJ	Φ8 Spring Washer	Φ8弹垫圈	4
7	210221-Z1000	Hex Nut	六角螺母	4
8	54100-22H00	Hub, Front Wheel	前轮毂组件	1
8.1	60301 GB/T 278-82	Bearing	轴承	2
8.2	54123-22H00	Middle Bushing	前轮中间衬套	1
8.3	09284-Z1000	Dust Seal	防尘圈	1
9	54600-22H00	Gear Box Assy, Speedometer	计数器	1
10	54121-Z1000	Bushing, Front Wheel, L	前轮左衬套	1
11	54711-22H00	Axle, Front Wheel	前轮轴	1
12	GB/T 6187.2 M12-Zn.DJ	M12 Flange Nut	M12法兰自锁螺母	1

后轮：REAR WHEEL




A	65000-22H70	Rear Wheel Assy	后轮总成	1
1	55700-22H20	Tire	21×7-10外胎	1
2	55501-22H00	Valve	气门嘴	1
3	55550-22H10	Rim, Rear Wheel	后轮圈	1
4	GB/T 5783 M8X25-Zn.DJ	Hex Bolt	六角螺栓	4
5	GB/T 97.1 8-Zn.DJ	Φ8 Washer	Φ8平垫圈	4
6	GB/T 93 8-Zn.DJ	Φ8 Spring Washer	Φ8弹垫圈	4
7	210221-Z1000	Hex Nut	六角螺母	4
8	64100-22H10	Hub, Rear Wheel	后轮毂组件	1
8.1	64123-22H20	Middle Bushing	后轮中间衬套	1
8.2	GB/T 276 6301Z	Bearing	轴承	2
8.3	11133-03201	Dust Seal	防尘圈	2
9	C0205-1225J	Bushing, Rear Wheel, L	后轮左衬套	1
10	54711-22H00	Axle, Rear Wheel	后轮轴	1
11	GB/T 6187.2 M12-Zn.DJ	M12 Flange Nut	M12法兰自锁螺母	1

传动部分：TRANSMISSION



1	428MH-98	Chain 98 links	98节链条	1
2	64511-22H10	Rear Sprocket	大链轮	1
3	65301-29A20	Base, sproket	链轮座	1
3,1	GB/T 276 6203Z	Bearing	轴承	1
3,2	65344-29A00	Oil Seal	密封圈	1
4	T0270-1217B	Spacer	链轮座内衬套	1
5	65302-29A10	Buffer stopper	链轮缓冲块	4
6	64512-29A00	Locking plate	链轮锁片	2
7	GB/T 5783 M8X33-S12-Zn.DH	M8X33 Hex Bolt	M8X33六角螺栓	4
8	210221-Z1000	Nut	螺母	4
9	61410-22H00	Adjuster, Chain	链条调节器	2


CBS联合制动: CBS (COMBINED BRAKING SYSTEM)



A	79000-22H00	CBS Assy	CBS联合制动总成	1
1	79100-22H00	PVC Valve Assy.	PCV阀体组件	1
2	59600-22H00-SH001	Master Cylinder, Front Brake	前刹上泵总成	1
2.1	59286-22H00-SH001	Front Brake Lever	刹车手柄	1
2.2	59285-22H00-SH001	Front Brake Switch	前刹开关	1
3	59300-22H00-SH001	Caliper, Front Brake	前刹卡钳总成	1
3.1	59312-22H00-SH001	Front Brake Pad	前刹摩擦片	1
4	69600-22H00-SH001	Master Cylinder, Rear Brake	后刹上泵总成	1
5	69100-22H00-SH001	Caliper, Rear Brake	后刹卡钳总成	1
6	69112-22H00-SH001	Rear Brake Pad	后制动摩擦片	1
7	69210-22H00	Hose,PVC Valve	PCV阀体油管	1
8	59210-22H00	Hose, Master Cylinder, Front Brake	前刹上泵油管	1
9	59220-22H00	Hose,Caliper, Front Brake	前刹下泵油管	1
10	69220-22H00	Hose, Rear Disc Brake	后碟刹油管	1
11	59211-22H00	Front Brake Disc	前制动盘	1
12	59212-22H00	M8×27 Bolt	M8×27刹车盘安装螺栓	3


13	69211-22H00	Rear Brake Disc	后制动盘	1
14	69212-22H00	M8×25 Bolt	M8×25刹车盘安装螺栓	3
15	69810-22H00	Bracket, Rear Brake Main Pump	后制动主泵安装板	1
16	GB/T16674 M6X16-Zn.DJ	M6X16 Flange Bolt	M6X16法兰螺栓	2
17	GB/T16674 M6X25-Zn.DJ	M6X25 Flange Bolt	M6X25法兰螺栓	2
18	GB/T70.1 M8X16-Zn.DJ	M8X16 Bolt	M8X16内六角圆柱头螺栓	2
19	GB70.2-2000 M6X20-DJ	M8X12 Screw	M6X20内六角平圆头螺钉	2
20	GB/T16674 M6X12-Zn.DJ	M6X12 Flange Bolt	M6X12法兰螺栓	1
21	GB/T 16674 M8X32-9.8-Zn.DJ	M8X32 Flange Bolt	M8X32法兰螺栓	2
22	43110-22H20	Rear Brake Pedal Assy	后制动踏板组件	1
23	GB/T 97.1 16-Zn.DJ	Washer	平垫圈	1
24	GB/T 91 3.2X25-Zn.DJ	Cotter Pin	开口销	1
25	65330-22H00	Mounting Plate, Rear Caliper	后刹卡钳安装板	1
26	65310-Z1000	Torque Rod	扭力杆	1
27	70006-Z1000	Bolt, Torque Rod	扭力杆螺栓（长）	1
28	64206-29A00	Cushion	缓冲垫	1
29	09111-Z1000	Bolt, Torque Rod	螺栓	1
30	GB/T 6170 M8-S14-Zn.DJ	M8 Hex Nut	M8六角螺母	2
31	43121-22H00	Brake Return Spring	制动回位弹簧	1
32	37750-Z1000	Brake Switch, Rear	后刹开关	1
33	43331-Z1000	Spring	后刹开关弹簧	1
34	59242-22H00	Holder,Oil Cup	油杯支架	1

空滤： AIR CLEANER



1	13700-16H50	Air Cleaner Assy	空气滤清器总成	1
1,1	13723-16H10	Outlet Tube, Air Cleaner	空滤器连接口	1
1,2	13727-16H10	Inlet Tube, Air Cleaner	空滤器进气口	1
1,3	13725-16H10	Core, Air Cleaner	空滤器滤芯	1
2	13712-Y1000	Clip	卡箍	1

消音器：MUFFLER




1	14300-22H50	Muffler Comp(Color)	消音器	1
1,1	14321-22H00	Cover, Muffler	消音器装饰板	1
1,2	14322-22H00	Cover, Exhaust Pipe	排气管装饰板	1
1,3	Q/DPT-6X12-A2-70-304	M6×12 Screw	M6×12十字盘头螺栓	2
1,4	GB/T 97.1 6-A2-70-304	Washer	平垫圈	8
1,5	GB/T 859 6-A2-70-304	Spring Washer	轻型弹簧垫圈	8
2	14360-Z1000	Gasket, EXhaust Pipe	排气管密封垫	1
3	GB/T 6177 M6-A2-70-304	M6 Flange Nut	M6法兰螺母	2
4	14302-22H00	Cushion Washer	消音器缓冲胶圈	1
5	14301-22H00	Cushion Bushing	消音器缓冲衬套	2
6	GB/T16674 M10X30X1.25-Zn.DJ	M10×30 Flange Bolt	M10×30法兰螺栓	2

前后泥板：FRONT&REAR FENDER




1	53110-22H00	Front Fender	前泥板	1
2	51510-22H10	Holder,Front Fender, Lh	前挡泥板支架（左）	1
3	51520-22H00	Holder,Front Fender, Rh	前挡泥板支架（右）	1
4	Q/DPT-6X16-A2-70-304	M6×16 Screw	M6×16加大盘头螺钉	4
5	GB/T 6187.2 M6-Zn.DJ	M6 Flange Nut	M6法兰自锁螺母	4
6	63111-22H00	Rear Fender	后泥板	1
7	63121-22H00	Cushiong, Rear Fender	后泥板缓冲垫	2
8	63112-22H00	Rear Fender Bracket	后泥板内支架	1
9	GB/T16674 M6X16-Zn.DJ	M6×16 Flange Bolt	M6×16法兰螺栓	4
10	GB/T 96 6-Zn.DJ	Φ6 Washer	Φ6大垫圈	2

油箱:FUEL TANK




1	44100-22H30	Fuel Tank Comp	油箱	1
2	44222-14A00-G3	Fuel Cap	油箱盖	1
3	46123-Z1000	O-Ring	O形缓冲圈	1
4	14315-Y1000	Step Spacer	台阶衬套	1
5	44104-22H01	Separating Plate, Fuel Tank	油箱隔离板	1
6	34810-16H00	Fuel Level Gauge	油位计	1
7	G1000-4080P	Hose	油管	1
8	GJD00-8010C	Clip	油管夹	2
9	GB/T16674 M6X12-Zn.DJ	M6×12 Flange Bolt	M6×12法兰螺栓	6
10	GB/T16674 M6X20-Zn.DJ	M6×20 Flange Bolt	M6×20法兰螺栓	1

燃油蒸发系统: EVAPORATION SYSTEM



1	44810-15AD0	Carbon Canister (OX-TGM-2)	碳罐	1
2	44910-17H00	Holder, Carbon Canister	碳罐支架	1
3	GB/T 6177.1 M6-Zn.DJ	M6 Flange Nut	M6法兰防滑螺母	1
4	44820-18H00	Dumping Valve	倾倒阀	1
5	44401-17H00	Holder, Dumping Valve	倾倒阀支架	1
6	44110-22H00	T-Adapter	三通	1
7	G1000-4080P	Hose	油管	4
8	GJD00-8010C	Clip	油管夹	8

护板: PLASTICS



1	46110-22H00	Cover, Frame	车架横梁护罩	1
2	47316-10H00	Cushion Washer	椭圆橡胶圈	1
3	46705-14A00	Rubber	胶套	1
4	34555-Y1000	Cushion Washer	橡胶垫圈	2
5	GB/T 96 6-Zn.DJ	Φ6 Washer	Φ6大垫圈	2
6	GB/T16674 M6X12-Zn.DJ	M6X12 Flange Bolt	M6X12法兰螺栓	2
7	47111-22H00	shield, Lh	左护板	1
8	47211-22H10	shield, Rh	右护板	1
9	Q/DPT-6X16-A2-70-304	Screw	M6×16加大盘头螺钉	3
10	09321-21H00	Cushion Washer	缓冲圈	3

链罩/工具固定板: CHAIN GUARD&TOOL HOLDER



1	61311-22H00	Chain Case	链罩	1
2	GB/T16674 M6X10-Zn.DJ	M6×10 Flange Bolt	M6×10法兰螺栓	2
3	46820-22H00	Holder, Tool Holder	工具固定板	1
4	41522-14A00	Band, Tool Kits	工具攀带	1
5	GB/T16674 M6X12-Zn.DJ	M6X12 Flange Bolt	M6X12法兰螺栓	2

后货架/后牌支架:REAR CARRIER / LISENCE PLATE HOLDER



1	46210-22H00-000	Rear Carrier	后货架	1
2	GB/T 97.1 8-Zn.DJ	M8 Washer	M8平垫圈	4
3	GB70.1-2000 M8X16-Zn.DJ	M8×16 Bolt	M8×16内六角圆柱螺栓	4
4	63210-22H00	Bracket, License Plate	后牌照支架安装板	1
5	45530-Y1000	License Support	后牌照支架	1
6	GB/T16674 M6X12-Zn.DJ	M6X12 Flange Bolt	M6X12法兰螺栓	4

座垫:SEAT



1	45100-22H00	Seat Assy (Color)	座垫总成	1
2	GB/T 882-1986 B型	Pin	销轴	2
3	GB/T 97.1 6-Zn.DJ	Φ 6 Washer	Φ 6平垫圈	2
4	GB/T 91 1.6X16-Zn.DJ	Φ1.6X16 Cotter Pin	Φ1.6X16开口销	3
5	45111-22H00	Pin	座垫锁销	1
6	45112-22H00	Spring	锁销弹簧	1
7	GB/T 97.1 8-Zn.DJ	Washer	Φ 8平垫圈	1

后视镜： REAR MIRROR



1	56500/56600-Y1000-SZ037	Rearview Mirror Assy	后视镜总成	1
---	-------------------------	----------------------	-------	---

操纵线： CABLES



1	58400-22A00	Clutch Cable	离合线	1
2	58300-22H20	Throttle Cable	油门线	1
3	57514-21H00	Clutch Cable Cover	离合线护套	1

贴花 STICKERS



1	89012-16A00	Fuel Tank Emblem	商标贴花	2
2	89081-22H00	Sticker, Shield, Lh	左护板贴花	1
3	89082-22H00	Sticker, Shield,Rh	右护板贴花	1