

T9 Scooter PARTS CATALOG

MASTER T9 TY125T-25D EFI Euro4



SUMCO Master 125 TIANYIN T9 TY125T-25D EFI Euro4 2020

TEYIN TIANYIN TY125T-25D e6*168/2013*00086*00


Frame No:#LM0CJV25.....# (Shanqi Tianying RIYA)

RIYA TIANYIN T9 TY125T-H EFI Euro4 2017

Shanqi Tianying Vehicle TY125T-H e50*168/2013*00014*00


Frame No:#LUJTCJPH.....# (Shanqi Tianying RIYA)

FRAME BODY




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-01-001	FRAME BODY	车架	1
2	TY125T-H-01-002	BRACKET,COVER FR	前面板支架	1
3	TY125T-H-01-003	BOLT FLANGE M8×25	六角法兰螺栓M8×25	2
4	TY125T-H-01-004	BOLT FLANGE M8×20	六角法兰螺栓M8×20	1
5	TY125T-H-01-005	BAR R STEP ASSY	右脚蹬	1
6	TY125T-H-01-006	BAR L STEP ASSY	左脚蹬	1
7	TY125T-H-01-007	PIN SPLIT 1.6*15	后脚蹬插销	1
8	TY125T-H-01-008	PIN RR STEP 6*31.5	后脚蹬销轴	1
9	TY125T-H-01-009	BOLT FLANGE 10*55	六角法兰螺栓M8×55	2
10	TY125T-H-01-010	HANGER OF ENGINE	发动机吊架	1
11	TY125T-H-01-011	BUSH SWING LOCK	发动机吊架衬套	1
12	TY125T-H-01-012	NUT FLANGE 10MM	六角法兰螺母M10	3
13	TY125T-H-01-013	FLANGE BOLT M10×1.25×235	六角法兰螺栓M10*235	1
14	TY125T-H-01-014	RUBBER STOPPER A	发动机吊架缓冲胶A	1
15	TY125T-H-01-015	RUBBER STOPPER B	发动机吊架缓冲胶B	1
16	TY125T-H-01-016	ECU INSTALLING BRACKET	ECU安装支架	1
17	TY125T-H-01-017	ECU (ELECTRIC CONTROL UN	ECU微电脑控制器	1

FENDER




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-02-001	FRONT FENDER	前轮泥板	1
2	TY125T-H-02-002	NUT 6M M	六角法兰螺母M6	2
3	TY125T-H-02-003	REFLEX REFLECTOR SIDE	侧反射器	2
4	TY125T-H-02-004	BOLT FLANGE M6×16	六角法兰螺栓M6×16	8
5	TY125T-H-02-005	FENDER RR TIRE	后轮挡泥板	1
6	TY125T-H-02-006	NUT (H EX) CAP 6M M	盖型螺母M6	4
7	TY125T-H-02-007	RIGHT BRACKET,FENDER RR TIRE	后轮泥板支架	1
8	TY125T-H-02-008	BRACKET,FENDER RR TIRE	后轮泥板右支架	1
9	TY125T-H-02-009	SPEEDOMETER CABLE CLAP	里程线夹	1

BODY COVER




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-03-001	COVER R SIDE	右边盖	1
2	TY125T-H-03-002	COVER L SIDE	左边盖	1
3	TY125T-H-03-003	SCREW TAPPING 4*12 (K)	自攻丝	16
4	TY125T-H-03-004	Right trim panel	后右装饰板上部	1
5	TY125T-H-03-005	Lower left trim panel	后左装饰板下部	1
6	TY125T-H-03-006	Tail light upper cover	后装饰板上部连接板	1
7	TY125T-H-03-007	NUT SPRING 4MM	卡片	4
8	TY125T-H-03-008	Left trim panel	后左装饰板上部	1
9	TY125T-H-03-009	Lower right trim panel	后右装饰板下部	1
10	TY125T-H-03-010	REAR BOX ASSY	带尾箱状态	1
11	TY125T-H-03-011	REAR BOX	后货架, 安装尾箱状态	1
12	TY125T-H-03-012	REAR BOX CARRIER	尾箱	1
13	TY125T-H-03-013	BACKREST ASSY	带后靠背状态	1
14	TY125T-H-03-014	Tail light upper cover, For backrest	后装饰板上部连接板, 带靠背	1
15	TY125T-H-03-016	BACKREST	后靠背	1
16	TY125T-H-03-017	BACKREST BRACKET INSTALL	后靠背支架安装螺栓M8*30	3

REAR SHOCK ABSORBER



NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-04-001	Power connecting plate	动力连接板	1
2	TY125T-H-04-002	BOLT FLANGE M8×70	六角法兰面螺栓 M8×70	1
3	TY125T-H-04-003	BOLT FLANGE M8×60	六角法兰面螺栓 M8×60	1
4	TY125T-H-04-005	BOLT FLANGE M8×40	六角法兰面螺栓 M8×40	2
5	TY125T-H-04-006	CUSHION ASSY., R R .	后减震	2
6	TY125T-H-04-007	BOLT HEX 8*27	六角螺栓 M8×27	2
7	TY125T-H-04-008	NUT 10M M	自锁螺母	2
8	TY125T-H-04-008	NUT 10M M	六角法兰面自锁螺母 M8	2


FRONT FORK



NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-05-001	STEERING BAR	下联板	1
2	TY125T-H-05-002	BOLT FLANGE M8×45	六角法兰面螺栓 M8×45	4
3	TY125T-H-05-003	R.FR.FORK ASSY.	前右减震器	1
4	TY125T-H-05-004	L.FR.FORK ASSY.	前左减震器	1
5	TY125T-H-05-005	FULL SET STEEL BOWL	钢碗总成	1
6	TY125T-H-05-005	TOP NUT,STEERING STEM	柱顶螺母	2
7		BOWL 1	上钢盘	1
8		BALL ASSY.,UPPER	上钢珠	22
9		BEAR ING TOP STRG	上轴承座	1
10		BOWL 2	下钢碗	1
11		BALL ASSY.,LOWER	下球架钢珠组件	17
12		BEAR ING BOT STRG	下轴承座	1

FUEL TANK

11




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-06-001	CAP SET FILLER	电喷专用油箱盖	1
2	TY125T-H-06-002	FUEL TANK	油箱	1
3	TY125T-H-06-003	COMMON FUEL TUBE	油管	1
4	TY125T-H-06-004	DUMP VALVE	倾倒阀	1
5	TY125T-H-06-005	THREE-WAY VALVE	三通阀	1
6	TY125T-H-06-006	COMMON FUEL TUBE	油管	2
7	TY125T-H-06-007	CARBON CANISTER SOLENOID	碳罐电磁阀	1
8	TY125T-H-06-008	CLAMP $\phi 10$	碳罐电磁阀卡箍 $\phi 10$	3
9	TY125T-H-06-009	CLAMP $\phi 8.3$	碳罐电磁阀卡箍 $\phi 8.3$	1
10	TY125T-H-06-010	FUEL SENSOR ASSY	传感器总成（电喷专用）	1
11	TY125T-H-06-011	COMMON FUEL TUBE	油管	1
12	TY125T-H-06-012	CLAMP $\phi 8.3$	卡簧	4
13	TY125T-H-06-013	CARBON CANISTER OX-TGM-2	碳罐OX-TGM-2 OXIN-A	1
14	TY125T-H-06-014	HIGH VOLTAGE FUEL TUBE	高压油管6×12350mm	1
15	TY125T-H-06-015	HIGH VOLTAGE FUEL TUBE	高压油管6×12130mm，	1
16	TY125T-H-06-016	HIGH VOLTAGE FUEL TUBE	高压油管6×12200mm，	1
17	TY125T-H-06-017	DEDICATED CATHODIC JOINT	油管专用阴极接头	3
18	TY125T-H-06-018	CLAMP FOR HIGH VOLTAGE F	高压油管抱箍	6
19	TY125T-H-06-019	THROTTLE VALVE ASSY	节气门阀体总成	1

20	TY125T-H-06-020	HORIZONTAL FUEL PUMP	卧式电子油泵	1
21	TY125T-H-06-021	SENER CLIP	传感器卡片	1
22	TY125T-H-06-022	SENER SEALING GASKET	传感器密封垫	1


6

SEAT ASSY




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-07-001	SEAT	座垫	1
2	TY125T-H-07-002	HINGE ASSY SEAT	座垫摇臂	1
3	TY125T-H-07-003	PIN LOCK 8M M	波纹销	2
4	TY125T-H-07-004	WASH PLAIN 8MM	垫片M8	2
5	TY125T-H-07-005	Cushion gas spring	座垫气弹簧	1
6	TY125T-H-07-006	RUBBER STOPPER A	发动机吊架橡皮A	1
7	TY125T-H-07-007	BOLT FLANGE M6×12	六角法兰螺栓M6×12	8
8	TY125T-H-07-008	LID CARB MAINT	保养盖	1
9	TY125T-H-07-009	SCREW TAPPING 4*12 (K)	自攻丝	7
10	TY125T-H-07-010	COVER BATTERY	电池盒盖	1
11	TY125T-H-07-011	BOLT FLANGE M8×25	六角法兰螺栓 M8×25	4
12	TY125T-H-07-012	Right rear shelf	右后扶手	1
13	TY125T-H-07-013	Left rear shelf	左后扶手	1
14	TY125T-H-07-014	CABLE OF SEAT LOCK	座垫拉锁	1
15	TY125T-H-07-015	SCREW SPECIAL	十字大圆头螺栓M6*14	1
16	TY125T-H-07-016	LUGGAGE BOX ASSY	杂物箱	1
17	TY125T-H-07-017	LOCK BASE OF SEAT	座垫锁	1
18	TY125T-H-07-018	COLLAR HINGE ASSY SEAT	座垫绞脸衬套	2
19	TY125T-H-07-019	BOLT FLANGE M6×20	六角法兰螺栓M6×20	8

FRONT WHEEL




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-08-001	FRONT WHEEL	前轮总成	1
2	TY125T-H-08-002	VALVE RIM	气门嘴	1
3	TY125T-H-08-003	DISK FR BRAKE	前碟刹盘	1
4	TY125T-H-08-004	BOLT FR DISK 8*24	碟刹螺丝M8*25	3
5	TY125T-H-08-005	NUT U FLANGE	自锁螺母M12	1
6	TY125T-H-08-006	GEAR BOX ASSY FOR CALCUL	电感式计速器	1
7	TY125T-H-08-007	COLLAR RR AXLE	前轮衬套	1
8	TY125T-H-08-008	AXLE FR WHEEL	前轮轴	1
9	TY125T-H-08-009	FRONT RIM 14"	前铝轮14"	1
10	TY125T-H-08-010	FRONT TIRE 120/80-14, CST	前轮胎120/80-14 , 正新	1

BRAKE SYSTEM




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-09-001	FRONT AND REAR GANGED D	前后联动碟刹	1

REAR WHEEL



NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-10-001	REAR BRAKE DISK	后碟刹盘	1
2	TY125T-H-10-002	VALVE RIM	气门嘴	1
3	TY125T-H-10-003	REAR TIRE,13",CST	后轮胎130/60-13,正新	1
4	TY125T-H-10-004	REAR RIM;13"	后轮辋13 "	1

HANDLE BAR




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-11-001	WIND SCREEN	挡风玻璃	1
2	TY125T-H-11-002	RUBBER WIND SCREEN	挡风玻璃橡胶	1
3	TY125T-H-11-003	BO LT W ASH ER5*20	十字小圆头5*20	4
4	TY125T-H-11-004	THROTTLE CABLE	电喷专用油门线	1
5	TY125T-H-11-005	THROTTLE GRIP,HANDLE	右手把胶套	1
6	TY125T-H-11-006	L.GRIP,HANDLE	左手把胶套	1
7	TY125T-H-11-007	END HANDLE	方向把平衡块堵头	2
8	TY125T-H-11-008	BOLT W ASH M 8*60	内六角螺栓8*60	2
9	TY125T-H-11-009	MIRROR ASSY R BACK	右后视镜（含橡胶帽）	1
10	TY125T-H-11-010	MIRROR ASSY L BACK	左后视镜（含橡胶帽）	1
11	TY125T-H-11-011	SWITCH,HANDLEBAR R.	右组合开关	1
12	TY125T-H-11-012	SWITCH,HANDLEBAR L.	左组合开关	1
13	TY125T-H-11-013	SCREW PAN 5*25	十圆头5*25	1
14	TY125T-H-11-014	SCREW PAN 5*32	十圆头5*32	1
15	TY125T-H-11-015	HANDLE BAR	方向把	1
16	TY125T-H-11-016	BOLT WASH M 8*30	内六角螺栓8*30	4
17	TY125T-H-11-017	HOLD ER HANDLE PIPE	方向把压块	2
18	TY125T-H-11-018	CLIP, BRAKEHO SE(TOP BRIDC	方向把固定座板	1
19	TY125T-H-11-019	BOLT M10*45	六角螺栓10*45	2
20	TY125T-H-11-020	HANDLE COVER UP	方向把上罩	1
21	TY125T-H-11-021	Cover the upper cover	方向把上小盖	1
22	TY125T-H-11-022	CABLE COMP RR BRK	手制动线	1
23	TY125T-H-11-023	HANDLE COVER LOW	方向把前罩	1
24	TY125T-H-11-024	Instrument cover decorative cover	仪表罩装饰盖	1

25	TY125T-H-11-025	SCREW TAPPING 4*12 (K)	自攻丝	4
26	TY125T-H-11-026	Instrument cover	方向把后罩	1
27	TY125T-H-11-027	NUT SPRING 4MM	卡片	2
28	TY125T-H-11-028	HOLD LOW HANDLE PIPE	方向把固定座	2
29	TY125T-H-11-029	NUT 10M	自锁螺母M10	1
30	TY125T-H-11-030	BUSH,HANDLE BAR	方向把衬套	1
31	TY125T-H-11-031	BOLT FLANGE M8-10×55	六角法兰面螺栓M10×1.25×55	1


11

STAND ASSY




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-12-001	SPRING OF SIDE STAND	单撑弹簧	1
2	TY125T-H-12-002	SCREW SIDE STAND PIVOT	单撑台阶螺栓M10×25	1
3	TY125T-H-12-003	BOLT WASH ER6*20	十字小圆头6*20	2
4	TY125T-H-12-004	STAND ASSY MAIN	双撑	1
5	TY125T-H-12-005	SPRING OF MAIN STAND	双撑弹簧	1
6	TY125T-H-12-006	PIN LOCK 8M M	开口销	1
7	TY125T-H-12-007	AXLE MIAN STAND	双撑轴	1
8	TY125T-H-12-008	RUBBER STOPPER MAIN	双撑胶	1
9	TY125T-H-12-009	BOLT FLANGE M6×12	六角法兰螺栓M6×30	1
10	TY125T-H-12-010	BAR SIDE STAND	单撑	1

FRONT COVER




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-13-001	Front panel trim cover	挡风玻璃护盖	1
2	TY125T-H-13-002	SCREW TAPPING 4*12 (K)	自攻丝	18
3	TY125T-H-13-003	LID BRACKET,COVER FR	前面板支架小盖	1
4	TY125T-H-13-004	BOLT FLANGE M6*12	六角法兰螺栓M6*12	2
5	TY125T-H-13-005	front panel	前面板装饰盖	1
6	TY125T-H-13-006	Front right trim panel	前右装饰板	1
7	TY125T-H-13-007	Front left trim panel	前左装饰板	1
8	TY125T-H-13-008	Decorative strip for right decorative	前装饰板右边条	1
9	TY125T-H-13-009	Decorative strip for left decorative	前装饰板左边条	1
10	TY125T-H-13-010	NUT SPRING 4MM	卡片	14
11	TY125T-H-13-011	Left front trim panel cover	左前装饰板小盖	1
12	TY125T-H-13-012	Right front trim panel cover	右前装饰板小盖	1
13	TY125T-H-13-013	Ventilation grid	前内泥板	1
14	TY125T-H-13-014	Lower front left trim panel	前左装饰板下部	1
15	TY125T-H-13-015	Lower front right trim panel	前右装饰板下部	1

FLOOR PANEL




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-14-001	Tool kit	工具箱	1
2	TY125T-H-14-002	SCREW TAPPING 4*12 (K)	自攻钉	18
3	TY125T-H-14-003	COVER R LEG SIELD UP	右工具箱上盖	1
4	TY125T-H-14-004	COVER L LEG SIELD UP	左工具箱上盖	1
5	TY125T-H-14-005	COVER MIAN LOCK	电门锁盖	1
6	TY125T-H-14-006	COVER R INTER LID FR INTER	右工具箱内盖	1
7	TY125T-H-14-007	COVER L INTER LID FR INTER	左工具箱内盖	1
8	TY125T-H-14-008	COVER R OUTER LID FR INTER	右工具箱外盖	1
9	TY125T-H-14-009	COVER L OUTER LID FR INTER	左工具箱外盖	1
10	TY125T-H-14-010	COVER UNDER	车架底板	1
11	TY125T-H-14-011	PAN EL FLO O R	脚踏板	1
12	TY125T-H-14-012	Right guard	右中护板（车体右装饰板）	1
13	TY125T-H-14-013	Left guard	左中护板（车体左装饰板）	1
14	TY125T-H-14-014	NUT SPRING 4MM	卡片	8
15	TY125T-H-14-015	BOLT FLANGE M6×20	六角法兰螺栓M6×20	4
16	TY125T-H-14-016	Tank bracket	油箱支架	1
17	TY125T-H-14-017	PIN LO C K 8M M	波浪销	1
18	TY125T-H-14-018	LID FUEL CAP MAIN T	油箱上盖	1

SPEEDOMETER




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-15-001	SPEEDOMETER ASSY.(MILE/D	仪表总成	1
2	TY125T-H-15-002	SCREW TAPPING 4*12 (K)	自攻丝	4

HEADLIGHT



NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-16-001	HEADLIGHT	前大灯	1
2	TY125T-H-16-002	BULB OF HEADLIGHT 12V 35/3	大灯灯泡12V 35/35W	2
3	TY125T-H-16-003	SOCKET COMP	大灯线组	1
4	TY125T-H-16-004	SCREW TAPPING 4*12 (K)	自攻丝	6
5	TY125T-H-16-005	NUT SPRING 4MM	卡片	3


WINKER



NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-17-001	W IN KER ASSY.. R . FR	前右转向灯	1
2	TY125T-H-17-002	W IN KER ASSY.. L . FR	前左转向灯	1
3	TY125T-H-17-003	SCREW TAPPING 4*12 (K)	自攻丝	8
4	TY125T-H-17-004	Front position lamp	前位置灯	1

17

TAILLIGHT




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-18-001	RIGHT TAILLIGHT ASSY	后尾灯	1
2	TY125T-H-18-002	SCREW TAPPING 4*16 (K)	自攻丝	2
3	TY125T-H-18-003	R.RR.TURNING LIGHT ASSY	后右转向灯	1
4	TY125T-H-18-004	SCREW TAPPING 4*12 (K)	自攻丝	6
5	TY125T-H-18-005	BOLT FLANGE M6×16	六角法兰螺栓M6×16	2
6	TY125T-H-18-006	LICENSE PLATE LAMP	后牌照灯	1
7	TY125T-H-18-007	FLANGE NUT M6	螺帽M6	2
8	TY125T-H-18-008	REAR REFLECTOR	方形反光片	1

9	TY125T-H-18-009	FLANGE NUT M6	螺帽M6	2
10	TY125T-H-18-010	SCREW TAPPING 4*12 (K)	自攻丝	2
11	TY125T-H-18-011	REAR FENDER	后泥板	1
12	TY125T-H-18-012	SCREW TAPPING 4*16 (K)	自攻丝	2
13	TY125T-H-18-013	L.RR.TURNING LIGHT ASSY	后左转向灯	1


18

ELECTRICAL SYSTEM




NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-19-001	EFI DEDICATED MAIN WIRE H	电喷专用主电缆	1
2	TY125T-H-19-002	MAIN LOCK ASSY	套锁总成	1
3	TY125T-H-19-003	HORN	喇叭	1
4	TY125T-H-19-004	BATTERY	12V-9A 蓄电池	1
5	TY125T-H-19-005	START RELAY	继电器	1
6	TY125T-H-19-006	DIRECT-CURRENT REGULATO	18级直流整流器	1
7	TY125T-H-19-007	IGNITION COIL COMP.	电喷专用高压包	1
8	TY125T-H-19-008	FLASHER	闪光器	1
9	TY125T-H-19-009	LOCK SET	电门锁锁盖	1
10	TY125T-H-19-010	CATHODE LINE	负极线1长1短	2
11	TY125T-H-19-011	FUSE 10A	保险丝15A	2
12	TY125T-H-19-012	BOLT HEX 5*20	十字槽盘头螺栓M6×16	2
13	TY125T-H-19-013	BOLT FLANGE SH	六角法兰M6*12	3
14	TY125T-H-19-014	BO LT W ASH M 8*30	内六角螺栓8*30	4
15	TY125T-H-19-015	STARTING ANIODIC WIRE	启动正极线	1
16	TY125T-H-19-016	EFI DEDICATED RELAY	电喷专用继电器	2
17	TY125T-H-19-017	Headlight controller	大灯控制器	1

AIR FILTER



NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-20-001	Air filter assy	空气滤清器组件 (鹰王款)	1
2	TY125T-H-20-002	Air filter element	空气滤清器滤芯	1
3	TY125T-H-20-003	Air filter exit pipe clamp	空气滤清器出气管卡箍	1
4	TY125T-H-20-004	Hexagon flange bolts M6×25	六角法兰面螺栓 M6×25	2


EXHAUST SYST



NO.	PART CODE	En. Name	Ch. Name	Qty.
1	TY125T-H-21-001	EXHAUST MUFFLER ASSY.(CA	电喷专用排气消音器总成	1
2		TAIL C AP. M U FFLE	排气消声器尾盖	1
3		PAC KING PROTECTOR	防热垫片	6

4		BO LT W ASH ER 6*20	不锈钢带垫6*20	6
5	TY125T-H-21-005	MUFF. PROTECTOR	消音器外罩	1
6	TY125T-H-21-006	BOLT FLANGE M8×35	六角法兰螺栓M8×35	1
7	TY125T-H-21-007	BOLT FLANGE M8×55	六角法兰螺栓M8×55	1
8	TY125T-H-21-008	PROTECTOR . EXH PIPE	消音器弯管外罩	1
9	TY125T-H-21-009	NUT (H EX) CAP 8MM	盖型螺母M8	2
10	TY125T-H-21-010	GASKET OF EXHAUST PIPE	排气管密封垫	1
11	TY125T-H-21-011	PAC KING PROTECTOR	防热垫片	2
12	TY125T-H-21-012	BOLT FLANGE SH 6X16	不锈钢六角法兰螺栓6*12	2
13	TY125T-H-21-013	OXYGEN SENSOR	消声器氧传感器	1

TOOLS



NO.	PART CODE	DESCRIPTION	中文名称	QTY
1	TY125T-H-22-01	DRIVER'S TOOLS	随车工具	1

